


Partner: ClearOne  
 Model: INTERACT  
 Device Type: Conferencing



**GENERAL INFORMATION**

<b>SIMPLWINDOWS NAME:</b>	ClearOne INTERACT Single Channel Output Control v1.2
<b>CATEGORY:</b>	Conferencing
<b>VERSION:</b>	1.2
<b>SUMMARY:</b>	This module will control a single output channel on the ClearOne INTERACT.
<b>GENERAL NOTES:</b>	<p>This module will control a single output channel on the ClearOne INTERACT.</p> <p>Valid Interact AT outputs are</p> <ul style="list-style-type: none"> <li>1 for Record Out</li> <li>2 for Line Out</li> <li>3 for Speaker Out</li> </ul> <p>Valid Interact PRO outputs are</p> <ul style="list-style-type: none"> <li>1-8</li> </ul> <p>NOTE: The module "ClearOne INTERACT Feedback Processor v1.2" MUST be used to provide the initial processing of the responses from the ClearOne.</p>
<b>CRESTRON HARDWARE REQUIRED:</b>	C2COMI, C2COM-2/3
<b>SETUP OF CRESTRON HARDWARE:</b>	<p>RS232</p> <p>Baud: 57600</p> <p>Parity: N</p> <p>Data Bits: 8</p> <p>Stop Bits: 1</p> <p>RTS/CTS Handshaking should be enabled to insure no data is lost.</p>
<b>VENDOR FIRMWARE:</b>	1.0.28.0
<b>VENDOR SETUP:</b>	Flow control should be set to "on". The baud rate should be set to 57600.
<b>CABLE DIAGRAM:</b>	CNSP-141

**Partner: ClearOne**  
**Model: INTERACT**  
**Device Type: Conferencing**



### CONTROL:

<b>Volume_&lt;Up/Down&gt;</b>	D	Press and hold to adjust the attenuation for the selected crosspoint.
<b>Volume_Mute_&lt;On/Off/Toggle&gt;</b>	D	Pulse to turn the volume mute on and off.
<b>Number_Of_Open_Mics_&lt;On/Off/Toggle&gt;</b>	D	Pulse to turn the number of open mics on and off.
<b>Get_Initial_Status</b>	D	Pulse to get the current settings. THIS IS NOT TO BE USED FOR CONSTANT POLLING.
<b>Volume_Slider_In</b>	A	Analog input for the volume level. Valid range is 0d to 65535d.
<b>From_Processor_Module</b>	S	Serial input MUST be routed from the To_All_Other_Modules output on the "ClearOne INTERACT Feedback Processor v1.2" module.

### FEEDBACK:

<b>Volume_Mute_Is_&lt;On/Off&gt;</b>	D	High to indicate the current volume mute state.
<b>Number_Of_Open_Mics_Is_&lt;On/Off&gt;</b>	D	High to indicate the current number of open mics state.
<b>Unit_Parameter_Channel_Mismatch</b>	D	High to indicate that the selected unit, channel and parameter combination is not a valid combination.
<b>Volume_Level_Gauge</b>	A	Analog signal indicating the current volume level. To be displayed on a gauge on a touch panel.
<b>Volume_Level_Text</b>	S	Serial signal indicating the current volume level. To be displayed using indirect text on a touch panel.
<b>To_Device</b>	S	Serial signal to be routed to a 2-way serial com port.

**Partner: ClearOne**  
**Model: INTERACT**  
**Device Type: Conferencing**

**PARAMETER:**

<b>Volume_Step</b>	P	Select the desired volume step from the dropdown list. Default is 0.5dB.
<b>Unit_Type</b>	P	Select the unit type to control. Default is INTERACT PRO.
<b>Unit_ID</b>	P	At the time that v1.2 of the module was released, the only valid Unit_ID is ID0.
<b>Channel_ID</b>	P	Select the desired channel from the dropdown list.
<b>Parameter_ID</b>	P	Select the desired control point type from the dropdown list.

**TESTING:**

<b>OPS USED FOR TESTING:</b>	4.001.1012
<b>SIMPL WINDOWS USED FOR TESTING:</b>	4.03.20
<b>CRESTRON DB USED FOR TESTING:</b>	54.05.005.00
<b>DEVICE DB USED FOR TESTING:</b>	73.00.001.00
<b>SAMPLE PROGRAM:</b>	ClearOne INTERACT v1.2 Demo PRO2
<b>REVISION HISTORY:</b>	V. 1.0 – Original release. V. 1.2 – Incorporated 3-series best practices into all Simpl+.