


**Partner: Audio Control**  
**Model: Concert AVR-4**  
**Device Type: AV Receiver**



**GENERAL INFORMATION**



|                                    |   |
|------------------------------------|---|
| <b>SIMPLWINDOWS NAME:</b>          | Audio Control Concert AVR-4 v1.0  |
| <b>CATEGORY:</b>                   | Receiver/Processor  |
| <b>VERSION:</b>                    | 1.0   |
| <b>SUMMARY:</b>                    | This module will control power, volume, input select and surround mode select, and displays true feedback.  |
| <b>GENERAL NOTES:</b>              | This module provides control for most functions of the Audio Control Concert AVR-4. It also provides true feedback for several functions. Some front panel presses on the unit do NOT generate feedback. If all controls are done through the module, feedback should be true.<br>Other models this module will control:<br>-M4<br>*Tuner functions not present for Maestro M4 processor* |
| <b>CRESTRON HARDWARE REQUIRED:</b> | 2-Series Processor, C2COM3, 3-Series Processor  |
| <b>SETUP OF CRESTRON HARDWARE:</b> | RS232<br>Baud: 38400<br>Parity: None<br>Data Bits: 8<br>Stop Bits: 1  |
| <b>VENDOR FIRMWARE:</b>            | N/A   |
| <b>VENDOR SETUP:</b>               | N/A   |
| <b>CABLE DIAGRAM:</b>              | CNSP-124  |

Rear View of Connector



**CNSP-124**

Rear View of Connector



**Partner: Audio Control**  
**Model: Concert AVR-4**  
**Device Type: AV Receiver**


**CONTROL:**

|  |   |  |
|--|---|--|
| From_Device                            | S | Serial Data from device – tie to processor’s COM Port RX             |
| Poll                                   | D | Pulse to poll for all possible feedbacks. Runs for approx 1 min.     |
| Z1_Power_Toggle/On/Off                 | D | Pulse to power Zone 1 accordingly                                    |
| Z1_Volume_Mute_Toggle/On/Off           | D | Pulse to mute Zone 1 accordingly                                     |
| Z1_Volume_Up/Down                      | D | Press and hold to raise or lower Zone 1 Volume                       |
| Z1_Select_*                            | D | Pulse to select Zone 1 input   |
| Z1_Audio_Input_*                       | D | Pulse to select which audio input to use (Analog/Digital Audio/HDMI) |
| Z2_Power_On/Off                        | D | Pulse to power Zone 2 accordingly                                    |
| Z2_Volume_Mute_On/Off                  | D | Pulse to mute Zone 2 accordingly                                     |
| Z2_Volume_Up/Down                      | D | Press and hold to raise or lower Zone 2 Volume.                      |
| Z2_Select_*                            | D | Pulse to select Zone 2 input   |
| Z3_Power_On/Off                        | D | Pulse to power Zone 3 accordingly                                    |
| Z3_Volume_Mute_On/Off                  | D | Pulse to mute Zone 3 accordingly                                     |
| Z3_Volume_Up/Down                      | D | Press and hold to raise or lower Zone 3 Volume                       |
| Menu                                   | D | Pulse to bring up the main menu                                      |
| Select                                 | D | Pulse to press “select”  |
| Navigate_Up/Down/Right/Left            | D | Pulse to navigate the menus in the desired direction                 |
| Random                                 | D | Pulse to press “random”  |
| Repeat                                 | D | Pulse to press “repeat”  |
| Display_Brightness                     | D | Pulse to change display brightness                                   |
| Display_Processing_Mode/TimeDate/Cycle | D | Pulse what to show on the main unit’s display                        |
| Track_Foward/Back                      | D | Pulse to select Track Forward or Track Back                          |
| Cycle_Between_Decode_Modes             | D | Pulse to cycle between all available decode modes                    |

**Partner: Audio Control  
Model: Concert AVR-4  
Device Type: AV Receiver**



|                                 |   |   |
|---------------------------------|---|---|
| Direct_Mode_On/Off/Toggle       | D | Pulse to select Direct mode accordingly   |
| Room_EQ_On/Off_Toggle           | D | Pulse to toggle Room EQ on or off   |
| Dolby_Volume_On/Off_Toggle      | D | Pulse to toggle Dolby Volume on or off  |
| Bass_Control_Menu               | D | Pulse to bring up the Bass control menu   |
| Bass_Increment/Decrement        | D | Pulse to increase or decrease bass levels   |
| Speaker_Trim                    | D | Pulse to affect Speaker Trim  |
| Subwoofer_Control_Menu          | D | Pulse to bring up the Subwoofer control menu  |
| Subwoofer_Increment/Decrement   | D | Pulse to increase or decrease subwoofer levels  |
| Treble_Control_Menu             | D | Pulse to bring up the Treble control menu   |
| Treble_Increment/Decrement      | D | Pulse to increase or decrease treble levels   |
| Cycle_Output_Resolutions        | D | Cycle between all available output resolutions  |
| Cycle_Aspect_Ratios             | D | Cycle between all available aspect ratios   |
| Lipsync_Control_Menu            | D | Pulse to increase or decrease the lipsync timing by 1ms   |
| Favorite_Up/Down                | D | Pulse to move through the favorites   |
| Home                            | D | Pulse to press "home"   |
| Zone_Toggle                     | D | Pulse to toggle between zones   |
| Follow_Zone_1                   | D | Pulse to follow zone 1  |
| Headphones_Activate/Deactivate  | D | Pulse to trigger zone 1 mute relay so that one may listen to the headphones Without the speakers active |
| Tuner_Num_*                     | D | Pulse to press the Tuner numbers  |
| Tuner_Preset_Up/Navigate_Up     | D | Pulse to move up in the Tuner preset list, SELECT must be pushed afterword to take the selection        |
| Tuner_Preset_Down/Navigate_Down | D | Pulse to move down in the Tuner preset list, SELECT must be pushed afterword to take the selection      |
| Tuner_Up/Navigate_Right         | D | Pulse to tune up or navigate right  |
| Tuner_Down/Navigat_Left         | D | Pulse to tune down or navigate left   |

**Partner: Audio Control  
Model: Concert AVR-4  
Device Type: AV Receiver**



|  |   |  |
|--|---|--|
| Tuner_Band                             | D | Pulse for IR code for BAND (documented code, questionable functionality) |
| Tuner_Menu                             | D | Pulse for IR code for Tuner menu   |
| Tuner_Preset_Up/Sirius_Category_Up     | D | Pulse for Tuner preset up or Sirius category up                          |
| Tuner_Preset_Down/Sirius_Category_Down | D | Pulse for Tuner preset down or Sirius category down                      |
| Tuner_Page_Down_-_Preset_List          | D | Pulse to move down in the pages of the preset lists                      |
| Tuner_Store_Preset_X                   | D | Pulse to store preset X  |
| Tuner_Delete_Selected_Preset           | D | Pulse to delete selected preset  |
| RESET_TO_FACTORY_DEFAULTS              | D | Pulse to reset entire unit to factory defaults                           |
| REQUEST_*                              | D | Pulse to request   |
| Z1_Set_Tuner_Preset_*                  | D | Pulse to set zone 1 tuner preset #'s 1 through 50                        |
| Z2_Set_Tuner_Preset_*                  | D | Pulse to set zone 2 tuner preset #'s 1 through 50                        |
| Z3_Set_Tuner_Preset_*                  | D | Pulse to set zone 3 tuner preste #'s 1 through 50                        |

**Partner: Audio Control**  
**Model: Concert AVR-4**  
**Device Type: AV Receiver**


**FEEDBACK:**

|                           |   |   |
|---------------------------|---|---|
| To_Device\$               | S | Serial Data to device – tie to processor’s COM Port TX  |
| Polling_Busy              | D | Shows that polling is busy. Polling runs once at system startup.  |
| Z1_Power_is_*             | D | High when power is on or off accordingly  |
| Z1_Mute_is_*              | D | High when mute is on or off accordingly   |
| Z1_Volume_Level           | A | Zone 1 Volume level reported as an analog value between 0-65535   |
| Z1_Volume_Level_Percent\$ | S | Zone 1 Volume level reported back as TEXT with a “%” sign   |
| Z1_Current_Input\$        | S | Zone 1 Current input name as TEXT, correlates to <b>Z1_Input_*_Selected</b>   |
| Z1_Input_*_Selected       | D | Indicates which input is selected. Feedback is logic based, Front panel controls on unit do not all produce true feedback, so it is recommended that you only use the module to control the unit for feedback |
| Z1_Current_Audio_Input\$  | S | Zone 1 Current Audio input reported back as text – correlates to <b>Z1_Audio_Input_*_Selected</b>   |
| Z1_Audio_Input_*_Selected | D | Indicates which type of audio is currently being used as the source   |
| Z1_Current_Video_Input\$  | S | Zone 1 Current Video input reported back as text – correlates to <b>Z1_Video_Input_*_Selected</b>   |
| Z1_Video_Input_*_Selected | D | Indicates which video input is currently selected, this is true feedback from the unit  |
| Z1_Current_Video_Type\$   | S | Zone 1 Current Video Type reported back as Text – Correlates to <b>Z1_Video_Type_is_*</b>   |
| Z1_Video_Type_is_*        | D | Indicates which video type is currently selected  |
| Z2_Power_is_*             | D | High when power is on or off accordingly  |
| Z2_Mute_is_*              | D | High when mute is on or off accordingly   |
| Z2_Volume_Level           | A | Zone 2 Volume level reported as an analog value between 0-65535   |
| Z2_Volume_Level_Percent\$ | S | Zone 2 Volume level reported back as TEXT with a “%” sign   |
| Z2_Current_Input\$        | S | Zone 2 Current input name as TEXT, correlates to <b>Z2_Input_*_Selected</b>   |
| Z2_Input_*_Selected       | D | Indicates which input is selected. Feedback is logic based, Front panel controls on unit do not all produce true feedback, so it is recommended that you only use the module to control the unit for feedback |

**Partner: Audio Control**  
**Model: Concert AVR-4**  
**Device Type: AV Receiver**



|  |   |  |
|--|---|--|
| <b>Z2_Current_Video_Input\$</b>          | S | Zone 2 Current Audio input reported back as text – correlates to <b>Z2_Video_Input_*_Selected</b>                                |
| <b>Z2_Video_Input_*_Selected</b>         | D | Indicates which video input is currently selected, this is true feedback from the unit   |
| <b>Z3_Power_is_*</b>                     | D | High when power is on or off accordingly   |
| <b>Z3_Mute_is_*</b>                      | D | High when mute is on or off accordingly  |
| <b>Z3_Volume_Level</b>                   | A | Zone 3 Volume level reported as an analog value between 0-65535  |
| <b>Z3_Volume_Level_Percent\$</b>         | S | Zone 3 Volume level reported back as TEXT with a “%” sign  |
| <b>Current_Menu_Status\$</b>             | S | Text name value of Menu Status, Correlates to <b>Menu_Status_*</b>   |
| <b>Menu_Status_*</b>                     | D | Indicates which menu is currently open   |
| <b>Current_Display_Brightness\$</b>      | S | Text name value of current front panel display brightness (high, medium, low, off). Correlates to <b>Display_Brightness_is_*</b> |
| <b>Display_Brightness_is_*</b>           | D | Indicates the current display brightness level   |
| <b>Current_Decode_Mode_(2Ch)\$</b>       | S | Text name value of the current decode mode. Correlates to <b>Decode_Mode_(2ch)_*</b>   |
| <b>Decode_Mode_(2ch)_*</b>               | D | Indicates what 2ch decode mode is currently being usee   |
| <b>Current_Decode_Mode_(MultiCh)\$</b>   | S | Text name value of the current decode mode. Correlates to <b>Decode_Mode_(MultiCh)_*</b>   |
| <b>Decode_Mode_(MultiCh)_*</b>           | D | Indicates what MultiCh decode mode is currently being usee   |
| <b>Current_Direct_Mode_Status\$</b>      | S | Text name value of Direct Mode Status. Correlates to <b>Direct_Mode_is_*</b>   |
| <b>Direct_Mode_is_*</b>                  | D | Indicates Direct Mode accordingly  |
| <b>Current_Video_output_Resolution\$</b> | S | Text value of current video output resolution. Correlates to <b>Video_Out_Resolution_is_*</b>                                    |
| <b>Video_Out_Resolution_is_*</b>         | D | Indicates what the current Video output resolution is accordingly  |
| <b>Headphones_ARE_connected</b>          | D | Indicates after polling or requesting status of headphone that they are physically connected to the unit                         |
| <b>Headphone_are_NOT_connected</b>       | D | Indicates after polling or requesting status of headphones that they are Not connected to the unit                               |
| <b>Current_AM_Freq\$</b>                 | S | Text value of current AM Frequency   |

**Partner: Audio Control**  
**Model: Concert AVR-4**  
**Device Type: AV Receiver**



|                                   |   |  |
|-----------------------------------|---|--|
| Current_FM_Freq\$                 | S | Text value of current FM Frequency   |
| Current_FM_Genre\$                | S | Text value of current FM Genre   |
| Current_Sirius_Station_Name\$     | S | Text value of current Sirius station name  |
| Current_Sirius_Program_Type\$     | S | Text value of current Sirius program type  |
| Current_Sirius_DLS\$              | S | Text value of current Sirius DLS   |
| Network_Playback_Status_*         | D | Indicates the current state of network playback  |
| Current_Network_Playback_Status\$ | S | Text value of current network playback status. Correlates to <b>Network_Playback_Status_*</b>  |
| Current_Network_FILE/FOLDERName\$ | S | Text value of current network file or folder name  |
| Current_Z*_Tuner_Preset\$         | S | Text Value of Tuner Preset. Manufacturer lists values for all 3 zones, however only 1 tuner is available so these will typically mirror each other |
| Z*_Tuner_Preset_is_*              | D | Indicates what preset is currently selected  |
| Poll_Time                         | A | Parameter setting for polling time of Network Playback Status feedback   |

**TESTING:**

|                                  |   |
|----------------------------------|---|
| OPS USED FOR TESTING:            | 2-Series: v4.007.0004<br>3-Series: v1.005.0007  |
| SIMPL WINDOWS USED FOR TESTING:  | v3.11.15  |
| DEVICE DB USED FOR TESTING:      | v44.06.001.00   |
| CRES DB USED FOR TESTING:        | v33.01.004.10   |
| SYMBOL LIBRARY USED FOR TESTING: | V821  |
| SAMPLE PROGRAM:                  | Audio Control Concert AVR-4 v1.0 Demo PRO2.smw<br>Audio Control Concert AVR-4 v1.0 Demo MC3.smw |
| REVISION HISTORY:                | v1.0 – Original release.  |