


Partner: Bose
Model: ESP-88
Device Type: 4x4 Router Interface v1.0



GENERAL INFORMATION

| | |
|------------------------------------|--|
| SIMPLWINDOWS NAME: | Bose ESP 4x4 Router Interface v1.0 |
| CATEGORY: | Multi-Zone |
| VERSION: | 1.0 |
| SUMMARY: | This module controls a 4x4 Router object within the Bose ESP-88 configuration. |
| GENERAL NOTES: | This module controls a Router object within the Bose ESP-88 system. Please note that in the Bose configuration the Router name needs to be prefaced with an “#” (such as #Router). This enables the Bose unit to send unsolicited real-time feedback to the Crestron unit when any changes are made. |
| CRESTRON HARDWARE REQUIRED: | X-Series Processor, CNX-COM2, ST-COM, 2-Series Processor, C2COM3 |
| SETUP OF CRESTRON HARDWARE: | RS232 Baud: 38400 Parity: N Data Bits: 8 Stop Bits: 1 |
| VENDOR FIRMWARE: | None |
| VENDOR SETUP: | None |
| CABLE DIAGRAM: | CNSP-532 |



Partner: Bose
Model: ESP-88
Device Type: 4x4 Router Interface v1.0


CONTROL:

| | | |
|------------------|---|---|
| Set_Router_X-Y | D | Pulse to set the crosspoint (X,Y). |
| Set_Router_Off-Y | D | Pulse to turn of output Y. |
| Router_Enable | D | Latch high to enable serial communications with unit. |
| Router_Read | D | Pulse to poll for current router read status. |
| From_Device | S | Serial signal to be routed from an RS-232C port |

FEEDBACK:

| | | |
|-------------------|---|--|
| Router_Status_X-Y | D | Indicates the status of the current crosspoints (X,Y). |
| To_Device | S | Serial signal to be routed to an RS-232C port |

PARAMETER:

| | | |
|-------------|---|--|
| Step | A | Use to set the volume up/down step increment. |
| Module Name | D | The name of the Router module in the Bose ESP-88 configuration that this module will be communicating with. Note: The module name in the Bose configuration needs an “#” prefix, while the name entered in this module does not. |

TESTING:

| | |
|----------------------------------|------------------------|
| OPS USED FOR TESTING: | v3.155.1240 |
| SIMPL WINDOWS USED FOR TESTING: | v2.10.32 |
| DEVICE DB USED FOR TESTING: | 20.03.013.00 |
| CRES DB USED FOR TESTING: | 20.01.008.00 |
| SYMBOL LIBRARY USED FOR TESTING: | 576 |
| SAMPLE PROGRAM: | Bose ESP-88 Demo PRO2 |
| REVISION HISTORY: | v1.0 – Initial Release |