

LC300_LC300S

CaptureVision Station

User Manual - English



Version LCB021

[Important]

To download the latest versions of the Quick Start Guide, multilingual user manual, software, driver, etc., please visit Lumens

<https://www.MyLumens.com/support>

Table of Contents

Copyright Information.....	3
Chapter 1 Safety Instructions.....	4
Chapter 2 Package Contents.....	5
Chapter 3 Product Appearance and Connection.....	6
3.1 Product Appearance.....	6
3.2 Product Connection.....	7
3.3 RS-232 I/O Pin Description.....	7
Chapter 4 Function Description.....	8
4.1 Real-Time Operation Menu.....	8
4.2 Webpage Login Interface.....	8
4.3 Parameter Setting.....	9
4.4 Online Director.....	25
4.5 File Management.....	29
Chapter 5 Troubleshooting.....	33
Addendum 1.....	34

Copyright Information

Copyrights © Lumens Digital Optics Inc. All rights reserved.

Lumens is a trademark that is currently being registered by Lumens Digital Optics Inc.

Copying, reproducing or transmitting this file is not allowed if a license is not provided by Lumens Digital Optics Inc. unless copying this file is for the purpose of backup after purchasing this product.

In order to keep improving the product, the information in this file is subject to change without prior notice.

To fully explain or describe how this product should be used, this manual may refer to names of other products or companies without any intention of infringement.

Disclaimer of warranties: Lumens Digital Optics Inc. is neither responsible for any possible technological, editorial errors or omissions, nor responsible for any incidental or related damages arising from providing this file, using, or operating this product.

Chapter 1 Safety Instructions

Always follow these safety instructions when setting up and using the product:

1 Operation

- 1.1 Please use the product in the recommended operating environment, away from water or source of heat
- 1.2 Do not place the product on a tilted or unstable trolley, stand or table.
- 1.3 Please clean the dust on the power plug prior to usage. Do not insert the product's power plug into a multiplug to prevent sparks or a fire.
- 1.4 Do not block the slots and openings in the case of the product. They provide ventilation and prevent the product from overheating.
- 1.5 Do not open or remove covers, otherwise it may expose you to dangerous voltages and other hazards. Refer all servicing to licensed service personnel.
- 1.6 Unplug the product from the wall outlet and refer servicing to licensed service personnel when the following situations happen:
 - If the power cords are damaged or frayed.
 - If liquid is spilled into the product or the product has been exposed to rain or water.

2 Storage

- 2.1 Do not place the product where the cord can be stepped on as this may result in fraying or damage to the lead or the plug.
- 2.2 Unplug this product during thunderstorms or if it is not going to be used for an extended period.
- 2.3 Do not place this product or accessories on top of vibrating equipment or heated objects.

3 Cleaning

- 3.1 Disconnect all the cables prior to cleaning and wipe the surface with a dry cloth. Do not use alcohol or volatile solvents for cleaning.

4 Batteries (for products with batteries)

- 4.1 When replacing batteries, please only use similar or the same type of batteries.
- 4.2 When disposing of batteries or products, please adhere to the relevant instructions in your country or region for disposing of batteries or products.
- 4.3 Warning



The following situations must be avoided:

- Replace batteries that may affect the security protection due to errors in their form;
- Throwing batteries into flames or ovens, or subjecting batteries to mechanical squeezing or cutting that may cause an explosion;
- Place the battery in a high-temperature environment that may cause explosion or leakage of flammable liquids or gases;
- The battery is subjected to extremely low air pressure that may cause explosion or leakage of flammable liquid or gas.

■ FCC Warning

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

Notice:

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

■ IC Warning

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus," ICES-003 of Industry Canada.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe A prescrites dans la norme sur le matériel brouilleur: "Appareils Numériques," NMB-003 édictée par l'Industrie.

■ EN55032 CE Warning











Operation of this equipment in a residential environment could cause radio interference.

Warning: Operation of this equipment in a residential environment may cause radio interference

■ BSMI Warning (label displayed on the bottom of the device)

Warning: To avoid electromagnetic interference, this product should not be installed or used in residential environments


Chapter 2 Package Contents

LC300/LC300S	Power Adapter (DC 19V)	Power Cord	3-PIN to 2-PIN Connector
		 <p>Appearance may vary depending on country/region</p>	 <p>(For Japan only)</p>
USB 3.0 Cable (2M) (Type B to Type A)	RS-232 Connector (x2)	Mounting Metal Plate (x2)	M3 Metal Plate Screw (4x4)
			
Cable Holder-1	Cable Holder-2		
			


Chapter 3 Product Appearance and Connection

3.1 Product Appearance

▪ Front panel



▪ Rear panel




Note 12G-SDI is only applicable to LC300S

No	Name	Function Descriptions
1	Power	On/Off the device
2	USB3.0 Port	Can connect keyboard/mouse/USB flash drive/USB camera
3	LCM Screen	Display PGM screen / LCM menu / prompt message
4	Knob	<ul style="list-style-type: none"> ▪ Left/Right rotation: Adjust parameters and navigate the menu ▪ Press: Perform “confirm” action
5	Record	Start/Stop recording
6	Pause	Start/Pause recording
7	Stream	On/Off image streaming
8	Scenes	Switch the theme scene to the PGM screen. If there are multiple scenes, switch them in order
9	Reset	Reset the device (long press for 3 seconds to trigger it)
10	USB3.0 Port	Connect the computer to convert PGM audio and video into USB signal for use with video software <ul style="list-style-type: none"> ▪ Video/Audio source name: Lumens LC300(S) Processor
11	XLR Out	Balanced line output
12	Line In(1)	Line In audio source input
13	Line Out(1)	PGM audio output
14	XLR In	Balanced line input
15	3G-SDI	3G-SDI signal source input
16	HDMI In (4 CH)	HDMI signal source input <ul style="list-style-type: none"> ▪ HDMI 1 supports 4K resolution
17	HDMI Loop Through	Output HDMI 1 video screen
18	RS-232 Port	IN: Control the device through RS-232 OUT: Control the camera through RS-232
19	LAN	Connect to LAN, support searching for network cameras

20	WAN	Connect to WAN
21	HDMI 1 Multi View	Operation interface output; display the settings menu and image management
22	HDMI 2 Program	Main screen output, display the recording or streaming screen and layout
23	USB 2.0 Port	Can connect keyboard/mouse/USB flash drive/USB camera/LC-RC01 remote control panel
24	USB 3.0 Port	
25	Line In(2)	Line In audio source input
26	Line Out(2)	Multi View audio output
27	DC IN 19V	DC 19V power connector
28	12G-SDI In/ 12G-SDI Loop-through	Note For LC300S only 12G-SDI signal source output/input

3.2 Product Connection



*12G-SDI is only applicable to LC300S

3.3 RS-232 I/O Pin Description

RS-232 OUT RS-232 IN



■ RS-232 IN/ OUT

Function
TX+
RX-
GND

Chapter 4 Function Description

4.1 Real-Time Operation Menu

Connect the HDMI Multi View output to the display panel to show the real-time operation menu

Connect the keyboard/mouse through the USB port and use the keyboard/mouse to select the menu settings



No	Icon	Name	Function Descriptions
1		Configuration	Perform the system network setting, recording/streaming encoded setting
2		Director management	Input signal source selection, audio source management, recording/streaming control, output version selection, and network video camera control
3		File management	Conduct the video file content management, including the following functions: upload, download, delete, replay video files
4		About	Display the current firmware version and relevant production information of device
5	NA	Device IP	When WAN connects to the router, the current assigned device IP address will be displayed

4.2 Webpage Login Interface



No	Item	Function Descriptions
1	User Login Account	Enter user login account (default: admin)
2	User Password	Enter user password (default: admin) <ul style="list-style-type: none"> For a first-time login, please refer to 4.2.1 Account to change the default password
3	Language	Supporting English/Traditional Chinese/Simplified Chinese
4	Login	Log in to the administrator screen on the website

4.3 Parameter Setting

This Section provides descriptions of the web-based interface to control the display items. HDMI Multi View only provides item settings of [System Settings] > [Internet].

4.3.1 System Settings

4.3.1.1 System Settings

You may set up the device's basic information, initial date and time, and others here.

System Settings

1 Device Identification

Hostname :

 Device Description :

2 Live

3 Date and Time

Device Current Date and Time :
 2023-11-27 17:34:24
 Time Zone :

 Setting Mode :

 NTP Server URL :

4 Front panel lock

Front panel lock

5 Welcome Screen

File Format : PNG
 Size (Max.) : 3 MB
 Resolution(Max.) : 1920x1080

No	Item	Function Descriptions
1	Device Identification	Defines the device name and device description <input type="button" value="Note"/> Display name only accepts English characters and numbers

2	Live Streaming	Preview real-time PGM screen
3	Date & Time	<p>Supports different time zone setting. It can synchronize time with NTP service (default) and manual setup</p> <ul style="list-style-type: none"> ▪ Time Zone: Select the correct time zone according to current location ▪ Configuration Mode: <ul style="list-style-type: none"> ➤ NTP service: Synchronizes time with a network server ➤ Manual Setup: Sets time manually
4	Front Panel Lock	<p>Select to enable Front Panel Lock</p> <ul style="list-style-type: none"> ▪ After rebooting the device, it will remain locked. ▪ To disable this function, please log in to the web page to uncheck this item
5	Welcome Screen	<p>You can customize a welcome image for device</p> <ol style="list-style-type: none"> 1 Click [Browse] and select a file to upload. Once done, a thumbnail will be generated <ul style="list-style-type: none"> ※File format: <ul style="list-style-type: none"> ➤ File format: PNG ➤ File size (Max.): 3 MB ➤ Resolution size (Max.): 1920 x 1080 2 Click [Apply] to save this change. If you need to select another file, click [Cancel] and reselect a file

4.3.1.2 Network

The factory setting is DHCP. If you want to use a static IP address, please configure the connection here.

The screenshot shows the 'CaptureVision Station - Configuration' window. On the left is a dark sidebar menu with options: System (expanded), System Settings, Network (highlighted), Service, Configuration, Display, Remote Control Panel, Account, Source, Audio, Video, Scenes, Storage, Scheduler, Backup, and About. The main area is titled 'Network' and contains two sections: 'WAN Settings' and 'LAN Settings'. Both sections include a warning: 'The system will reboot after changing the network settings. Please re-login.' The 'WAN Settings' section has fields for IP Assignment (set to DHCP), IP Address (192.168.4.57), Subnet Mask (255.255.255.0), Default Gateway (192.168.4.254), Primary DNS Server (192.168.1.211), and Secondary DNS Server (192.168.1.212). The 'LAN Settings' section has fields for IP Assignment (set to DHCP), IP Address, Subnet Mask, Default Gateway, Primary DNS Server (undefined), and Secondary DNS Server. Both sections have an 'Apply' button at the bottom right.

Function Descriptions

- DHCP: Dynamic IP address as default
- Static IP: Configure static IP address according to the network and manually enter network information
Select and fill in required network setting information and click [Apply] to save the settings

Note The system will restart after changing network setting. Please connect and log in again

4.3.1.3 Services

CaptureVision Station - Configuration

System

- System Settings
- Network
- Service**
- Configuration
- Display
- Remote Control Panel

Account

Source

Audio

Video

Scenes

Storage

Scheduler

Backup

About

Service

1 Firmware

Master Firmware Version :
LCB021

Update

Advance

2 Service Data

Export the log file to your computer

Description :

Export

3 Reset

Reset to factory default

Except the network settings

Reset

4 Restart Device

Restart

No	Item	Function Descriptions
1	Firmware	Main firmware information and update Click [Update] and select the main firmware file to update Note Advance: Engineers update sub-firmware usage
2	Service Data	Saves system log files to user's computer 1 Enter file name 2 Click [Export] to export system log files Note The length of file name must be between 0 ~ 16 characters. Special symbols and space are forbidden
3	Reset	Restores the device to factory reset ▪ Check [Keep Network Settings] and the network settings will be remained
4	Restart Device	Restart the device

4.3.1.4 Configuration

You can export the configuration files of the device to a computer, and import the configuration files to another device to apply the same configuration.

No	Item	Function Descriptions
1	Export	Export the current configuration of device as a configuration file
2	Import	Import the exported configuration files from another device

4.3.1.5 Display

Function Descriptions
Select the HDMI PGM/Multi View output resolution for the device

4.3.1.6 Remote Control Panel

Function Descriptions
Remote control panel. Display the connection information of LC-RC01 remote control panel (optional). When there is no connection, a blank screen appears

4.3.2 Account

You can manage accounts for 3 kinds of user mode here: modify the username and password to [System Management], [Online Director], and [Content Management].

The screenshot shows the 'Account management' section of the 'CaptureVision Station - Configuration' interface. It features a left-hand navigation menu with options: System, Account, Source, Audio, Video, Scenes, Storage, Scheduler, Backup, and About. The main content area is divided into three sections, each with a red circled number:

- 1 Administrator:** Username field contains 'admin'. New Password and Confirm Password fields are empty. An 'Apply' button is at the bottom right.
- 2 Online Director:** Username field contains 'director'. New Password and Confirm Password fields are empty. An 'Apply' button is at the bottom right.
- 3 Video Manager:** Username field contains 'video'. New Password and Confirm Password fields are empty. An 'Apply' button is at the bottom right.

No	Item	Username/Password	Function Descriptions
1	Administrator	admin / admin	Top authority. Set up the permission of main system management
2	Online Director	director / director	Online Director function permissions, can manage playback and some basic video settings
3	Video Management	video / video	Views the permission of file storage and playback

Note

- The length of username must be between 4 ~ 16 characters. {}()'&@~^\$%",'`?:<>*V/#; symbols, and space are forbidden
- The length of password must be between 8 ~ 16 characters. {}()~^"|,':?<>*V; symbols, and space are forbidden
- Duplicate username is forbidden

4.3.3 Source

4.3.3.1 Physical Video Source Manager

- System >
- Account
- Source >
 - Physical Video Source
 - USB Video Source
 - Network Source Manager
 - Video Channel Manager

Physical Video Source

Physical Video Source Manager

ID	Source Name	Source Configuration	Visca Address	Protocol	Edit
1	Video Input 1	HDMI 1	N/A	N/A	
2	Video Input 2	HDMI 2	N/A	N/A	
3	Video Input 3	HDMI 3	N/A	N/A	
4	Video Input 4	HDMI 4	N/A	N/A	

Function Descriptions

Click [Edit] to edit the HDMI signal source name and resolution

- 3G-SDI video, can switch signal sources on the Video Input 4 edit page
- LC300S supports 12G-SDI signal sources and can switch signal sources on the Video Input 1 edit page

4.3.3.2 USB Video Source

- System >
- Account
- Source >
 - Physical Video Source
 - USB Video Source
 - Network Source Manager
 - Video Channel Manager

USB Video Source

USB Video Source

+ Add

ID	Source Name	Source Configuration	Delete
1	USB_Camera	Lumens VC-B2U Video Camera: Lum(3-6)	

Function Descriptions

Click [+Add], select the USB signal source device, apply it, and then add it

Note Please confirm that the USB signal source device is connected to the USB Type A port of the device

4.3.3.3 Network Source Manager

- System >
- Account
- Source >
 - Physical Video Source
 - USB Video Source
 - Network Source Manager
 - Video Channel Manager
- Audio >
- Video >
- Scenes >
- Storage
- Scheduler

Network Source Manager

Network Source

Refresh


Host Name	IP Address	MAC	Manufacturer	Status	Connected	Delete
VC-A71P-HN (HN-Default, 192.168.4.26)	192.168.4.26	-	-	Add	OK	
VC-A71P	192.168.4.164	DC:E2:AC:01:B3:35		Login	OK	
VC-A71P-HN	192.168.4.33	DC:E2:AC:02:B4:C3		Login	OK	

Network Stream


+ Add

Device Name	URL	Edit	Delete
VC-A51P	rtsp://192.168.4.154:8557/h264		

No	Item	Function Descriptions
1	Network Source	1 Click [Refresh] and automatically scan the network cameras in the same LAN

		<p>2 Click [Login Verification]/[Add] and enter login information to connect the camera</p>  <div style="border: 2px solid black; padding: 5px; margin-top: 10px;"> <p>Lumens Network Camera</p> <ul style="list-style-type: none"> ● CameraAccount: admin ● Password: 9999 </div> <p>3 Once the status display "OK", indicating that the image can be set under the signal source input selection</p>
2	Network Stream	<p>1 Click [Add]</p> <p>2 Select the stream type SRT/ RTSP, enter the network streaming name and URL, and then click [Apply]</p> <p>3 The newly added network streaming name will be displayed in the list</p>


4.3.3.4 Video Channel Manager



Function Descriptions

Click on [Edit], the online video sources will be displayed in a list, please drag the source to the desired channel


- Drag the signal sources to change their order



4.3.4 Audio Source Manager

- System >
- Account
- Source >
- Audio >
- Audio Source Manager
- Video >
- Scenes >
- Storage
- Scheduler
- Backup
- About

Audio



Audio output description
Line out(1): PGM
Line out(2): MULTI VIEW

Audio Source Manager

Refresh

USB Device Name	Format
Lumens VC-B2U Video Camera(3-6)	PCM, 16Bits, 44.1KHz

Function Descriptions

Click [Refresh] to search for the USB audio source device connected to the device

4.3.5 Video

Support flexible recording configurations, administrators can choose to record a single PGM (mixing video) screen or record 2 to 4 signal source screens, different videos can be set with different encoding settings

4.3.5.1 Encoder Manager

- System >
- Account
- Source >
- Audio >
- Video >
- Encoder Manager
- Record Manager
- Stream Manager

Encoder Manager

Encoder Profile Manager

Add Encoder Profile

Encoder Name	Video Compression	Resolution	FPS	Bitrate(Mbps)	Audio Compression	Edit	Delete
1080P_Profile	H.264	1920x1080	30	6	AAC		
4K	HEVC	3840x2160	60	15	AAC		

Function Descriptions

Click [Add Encoder Profile] to configure compression format/resolution/bit rate/audio sampling frequency settings

4.3.5.2 Record Manager

Function Descriptions

Click [Add] to configure the image/sound source and encoder

Note

- Support maximum recording time: 12 hours
- Resolution settings will affect the split-screen supported by PGM. Please refer to the following limitations

Resolution	PGM Maximum Split-screen Quantity	Description
4K 60fps	1 channel	
1080p 60fps	5 channels	1 channel PGM + 4 channel signal source screen

4.3.5.3 Stream Manager

Function Descriptions


Click [Add Stream Manager] to allow users to add stream settings.

Related settings must follow the streaming protocol and the settings recommended by server system support.

4.3.6 Scene

4.3.6.1 Scene

Provides 5 overlay styles, background images, and scenes. You can also add your own styles.




No	Item	Function Descriptions
1	Overlay	<p>Select and delete overlay style. You can upload files to apply. Click [+] and select a desired file from the window. Check the preview image and file name, and click [Apply] to start uploading and applying this overlay style. Click [Delete] to cancel the upload.</p> <p>※File format:</p> <ul style="list-style-type: none"> ➤ PNG format ➤ Supported size: (a) 1920 x 136 (b) 1080 x 240 (c) 800 x 320 (d) 640 x 400
2	Background	<p>Select and delete background image. You can upload files to apply. Click [+] and select a desired file from the window. Check the preview image and file name, and click [Apply] to start uploading and applying this background image. Click [Delete] to cancel the upload.</p> <p>※File format:</p> <ul style="list-style-type: none"> ➤ PNG format ➤ Supported size: 1920 x 1080
3	Scene	<p>Scene is the integration of “Overlay,” “Background Image,” and “Production Layout,” which provides the scene made of different background images, layout, and overlay style. You can customize the layout content in 30 scenes.</p> <p>Click [+] to open scene settings. Enter the scene name and select the required overlay, layout, and background image. Once done, click “Apply”.</p>

4.3.6.2 Macro

Supports 9 sets of macros, users can quickly switch themes, while the camera moves to the specified default position.


With the use of the LC-RC01 extension control panel (optional), the [1~3] buttons on the panel can trigger macro [1~3] settings.




No	Item	Function Descriptions
1	Scene Selection	Select a scene to be set <ul style="list-style-type: none"> If the layout style of the scene needs to be change, please refer to 4.3.6.1 Scene
2	Camera Preset Setting	Set [Camera Preset Position]. Each supports up to 9 sets of camera preset position selection and start/stop tracking <ul style="list-style-type: none"> After checking the box, the marco will preset the settings of the network camera on the assigned Channel 1 ~ 4



4.3.7 Storage

You can set up recording storage, cycle recording, and display hard drive information and NAS setting here.




No	Item	Function Descriptions
1	Record Disk Settings	Local storage: Click drop-down menu  and select local storage hard drive Formats supported: FAT/ FAT32/ NTFS/ ext3/ ext4/ exFAT
2	Disk Information	Display hard drive information, free space, and capacity. Click “Format” to clear the internal storage devices. Confirm if you want to format the hard drive in the pop-up dialog and click “Confirm” to delete all video files.
3	NAS Settings	Enable NAS mounting and related settings. <ul style="list-style-type: none"> It is required to go to Backup Setting> Upload Setting> Mode to select NAS. After recording, the video can be uploaded to NAS

4.3.8 Schedule Setting

No	Item	Function Descriptions
1	Schedule Settings	<ul style="list-style-type: none"> ■ Click [On/Off] : Enables/Disables schedule function ■ Click [Calendar] : Check the current schedule status Note Reset schedule source and replace the current schedule ■ Schedule source: <ul style="list-style-type: none"> ➤ Scheduling via the Panopto server: Enter the login information of the Panopto server to synchronize schedules ➤ Scheduling via the Opencast server: Enter the login information of the Opencast server to synchronize schedules ➤ Scheduling via the Kaltura server: Enter the login information of the Kaltura server to synchronize schedules ➤ Importing calendar manually: You can import iCalendar files (e.g. Outlook or Google Calendar) Click [Import] and select custom scheduled video file Note Only files in .ics format can be imported ➤ Importing calendar periodically You can synchronize schedules from network servers (e.g. Google Calendar) ● Please refer to the videos of How to series on Lumens™ YouTube channel for related settings
2	Stand by and Wake up	Enable/disable the scheduled standby and wake-up functions. Set the scheduled time after the functions are enabled.

4.3.9 Backup

Auto backup service, which can upload videos to a designated space automatically. You can set up upload destination and test the connection here.

No	Item	Function Descriptions
1	Backup Settings	<p>Auto upload: Disable / Upload right after recording completes / Upload periodically</p> <ul style="list-style-type: none"> Mode: FTP/ SFTP/ NAS/ USB Storage/ Panopto/ Kaltura FTP/ Kaltura SFTP/ Kaltura HTTPS/ Opencast HTTP/ Opencast HTTPS/ WebDAV http/ WebDAV https <p>Note Select NAS. Please go to Storage Settings > NAS Setting to enable mounting and related settings</p> <ul style="list-style-type: none"> Connection Test: Click [Connection Test]  to test if the current setting can be created

4.3.10 About

Display device-related Information: Firmware version, device serial number, and technical support link

System Information

Information

Manufacturer :
Lumens Digital Optics Inc.

Model :
LC300

Master Firmware Version :
LCB021



Serial Number :

WAN MAC :
DC:E2:AC:03:00:1A

LAN MAC :
DC:E2:AC:03:00:1B

Webpage :
www.MyLumens.com

Support :
service.lumens.com.tw



4.4 Online Director


LC300_LC300S is built in Online Director, which allows you to monitor recording and preview the output video from streaming director.

Three login methods below are available:


- Select Online Director from the HDMI Multi View real-time operation menu




- When login the web page, select the Online Director icon at the upper right corner on the parameter setting page



- When login the web page, use the Online Director account





Online Director related feature description as below:



No	Item	Function Descriptions
1	Channel	Video source screen output, display source screen preview
2	CUT	Switch the PVM screen to the PGM screen
3	Status	Displays current recording status, hard disk capacity and Internet connection status, etc.
4	PVM/PGM	Display preview (PVM) and actual output (PGM) screen
5	Record	Start/stop recording; also select whether to synchronously stream or not
6	Video	Select video signal, HDMI signal, network camera, streaming, or USB signal source screen
7	Audio	Manage the input and output audio sources; adjust the audio recording volume
8	Scenes	Fast select the required production layout, or customize the background and scene style
9	Camera Control	Provide video camera/PTZ control

4.4.1 REC Record Setting



No	Item	Function Descriptions
1	Synchronize	After checking the box, press recording button  to start/stop push and recording function
2	Record	Display streaming related information
3	Status	The push connection status will be highlighted
4	Start/Stop Recording	Start/stop recording, the start recording status bar will display the recording time

5	Pause	Pause Recording
6	Index	Timestamp can be added after the recording starts
7	Capture	Capture a photo
8	Single-channel Push Button	Push right away without starting recording function

4.4.2 Video

Function Descriptions


Preview Channel 1 ~ 4 signal sources screen, click on the screen to select the output signal source

- Please refer to [4.3.3.4 Image Distribution Management](#) for adding video sources.

4.4.3 Audio


No	Item	Function Descriptions
1	Set Delay Time	<p>Set audio delay time</p>
2	Audio Source	Select an audio source
3	Audio Volume	Display current audio volume scale
4	Volume Control	Adjust the volume of audio input
5	Mute/ Unmute	Mute/ Unmute audio output
6	+48V phantom Power	On/Off the +48V phantom power
7	PGM Level	The output volume control of the software mixer affects the volume of PGM recording/streaming
8	Audio Out Level	<ul style="list-style-type: none"> PGM HDMI: Set PGM HDMI volume MutltiView HDMI: Set Multi View HDMI volume Note Line out (2) volume synchronized Multi View HDMI volume Line Out(1) & XLR: Set the volume for Line Out (1) & XLR Note This field adjusts the volume and does not affect the recording/streaming volume

4.4.3 Scenes Layout Setting



No	Item	Function Descriptions
1	Scenes	Scenes page is the integration of "Overlay," "Background Image," and "Production Layout," which can perform a series of scene change according to your needs.
2	Layout	Apply a different layout to highlight the screen focus of different channels. Click the layout style to apply.
3	Overlay	Select a desired style to apply.
4	Background	Display the background images supported by "Online Director" system. Click the thumbnail to apply.

4.4.4 Camera Control




No	Item	Function Descriptions
1	Camera	Select a desired camera to control
2	Preset	Click number buttons to perform preset setting and calls
3	Direction Control	Move the center point to control the shooting direction Note Web interface do not support trackball controls. Please use arrow buttons to adjust the image direction
4	Zoom In/ Out	Zooms in/out the lens
5	Focus	Set up auto or manual focus
6	Tracking	Set the tracking function on/off Note This function is only applicable to tracking camera
7	PTZ Speed	Set up the moving speed of Pan Tilt Zoom

4.5 File Management


Perform the following functions via the file management interface: Upload, download, delete, replay video files and edit recording information.

4.5.1 Multi View Output Interface



No	Item	Function Descriptions
1	Preview	Click desired video files to play and control on the Preview screen
2	Program	Display the Director screen or switch to synchronize with the Preview screen
3	Screen Switch	Switch the Program screen to the LIVE Director screen or the Preview screen
4	Discovery	You can search recording video files by selecting date period on the calendar
5	Display Mode	Video view mode. You can switch to thumbnail mode or list mode
6	Folder	Display the recording video folders
7	Video File Display	Display the files in the video folder
8	File Management	Delete, backup or copy recording video to an external USB flash drive

4.5.2 Webpage Interface


The default page after accessing web page is system setting page. Click the video management icon  on the top-right corner to access video management page.

Video management





No	Item	Function Descriptions
1	Video Management	Click to access the video management page
2	Photo Management	Click to access the picture management page
3	Configuration	Click to access the system setting page <div style="border: 1px solid gray; padding: 2px; width: fit-content;">Note</div> Log in the web page with admin/admin to display system setting subpage If you log in the web page with video/video, you will not find the system setting subpage and you can only manage videos and photos
4	Online Director	Click to enter the Online Director page
5	Logout	Click this icon to log out the web page interface
6	File Management	Upload, download and delete the checked video files
7	Hard Drive Status	Display the used file and the capacity of the current hard drive
8	Video File Display	List information, including the file names of recording videos, thumbnails, capacity, and date

■ File Management Description


➤ Uploading

Check the thumbnails of the videos to upload. Click [] and the videos will be uploaded to the location set in Upload Settings. Please refer to [System Management/Upload Settings] for related settings.

Upload Status Description:


Icon	Upload Status	Icon	Upload Status
	Videos are uploaded successfully		Videos are queued for upload
	Fail to upload videos		Videos are uploading

➤ Downloading

Check the thumbnails of the videos to download. Click [] and the videos will be saved as MP4 video files and datasets.

If only video files are needed, you can click the video thumbnails and access video playback page to download the video files only.

➤ Delete

Check the thumbnails of the videos to delete. Click [] and the video files will be deleted permanently.

■ Video Playback


Right-click video to preview the video, edit the related content data, and download the video file and dataset

No	Item	Function Descriptions
1	Video Control Window	Play back and control recording videos
2	Video Content	Edit and modify video content
3	Video File and Dataset	Select the video files or datasets to download
4	Download	Click this button to download the checked video files or datasets
5	Apply	After editing and modifying the video content, click this button to apply

■ Photo Management


You can manage the photo files captured by pressing SNAPSHOT. Folders will be named with the shooting date automatically; all photos shot in the same date will be stored in the same folder.

Just like Video Management, you can also upload, download, and delete photos in Photo Management subpage.



Chapter 5 Troubleshooting

This chapter describes problems you may encounter while using LC300_LC300S. If you have questions, please refer to related chapters and follow all the suggested solutions. If the problem still occurred, please contact your distributor or the service center.

No.	Problems	Solutions
1.	Boot without power signal	Please confirm that the power cord used is of DC 19V specification
2.	No image output	<ol style="list-style-type: none"> 1. Check the power 2. Check if the input/output device cables are loose 3. Replace the cables and make sure they are not faulty 4. Make sure if the signal source connects to the device correctly 5. LC300/LC300S cannot record video from a video output including HDCP format 6. Confirm whether the machine is in standby mode. Tap any button on the device panel to wake the machine ^(*Note 1)
3.	The panel buttons are not responding	The panel become non-functional when logging into the system
4.	LC300/LC300S cannot perform camera control after connecting to a camera	Please make sure the dial setting of Camera Address Selector is 0. Device cannot identify camera correctly if it is not 0 
5.	You cannot log in the web page administration interface if you forget the password	Press the Reset button on the front panel to reset the device (hold press for 3 seconds)
6.	Webpage login failed	<ol style="list-style-type: none"> 1. Confirm whether the machine is in standby mode. Tap any button on the device panel to wake the machine ^(*Note 1) 2. Please confirm whether the password is correct. If you forget your password, please refer to Troubleshooting #5.
7.	LC300/LC300S cannot find the camera	<ol style="list-style-type: none"> 1. Please link to the webpage of the camera to make sure that [Setting] > [Video] > [Camera ID]/[Camera Location] in the webpage uses only English letters or numbers. The device cannot find the machine if you use special characters and space. 2. When the device is connected to a switch and the switch IGMP function is on, it will not be able to search for cameras in the local area network. Please disable the IGMP function first and then search for cameras again.
8.	LC300/LC300S supports maximum recording time	The maximum recording time which LC300/LC300S supports is 12 hours. 24/7 recording is not supported.

* Note 1: Standby Mode: Enable via RS232/TCP command.

Addendum 1

■ Frequently used port No.

Port No.	Description
1935/TCP	Applicable for RTMP push to most platforms, such as YouTube, Vimeo, and Twitch
80/TCP	Applicable for RTMP push to Periscope
443/TCP	Applicable for RTMPS push to Facebook
1935/TCP 1936/TCP	Applicable for RTMP push to LinkedIn
2935/TCP 2396/TCP	Applicable for RTMPS push to LinkedIn
443/TCP (HTTPS)	Applicable for platforms with built-in HTTPS security authentication, such as YouTube, Facebook, Ustream, Livestream, and Twitch
53/UDP (DNS)	Applicable to services of changing DNS IP address