





GENERAL INFORMATION			
SIMPLWINDOWS NAME:	Marantz SR9600		
CATEGORY:	Receiver/Processor		
VERSION:	V1.0		
SUMMARY:	This module controls and provides true feedback for the Marantz SR9600.		
GENERAL NOTES:	This module provides control for both zones on the SR9600. It also provides true feedback. NOTE: IN THE PREFERENCES MENU, YOU MUST SET THE STBY MODE TO NORMAL. IF YOU DO NOT CHANGE THIS SETTING, YOU WILL NOT BE ABLE TO TURN THE RECEIVER ON VIA RS232. NOTE: THIS MODULE IS FOR 2 SERIES PROCESSORS ONLY.		
CRESTRON HARDWARE REQUIRED:	C2COM, ST-COM		
SETUP OF CRESTRON HARDWARE:	RS232 Baud: 9600 Parity: None Data Bits: 8 Stop Bits: 1		
VENDOR FIRMWARE:	None		
VENDOR SETUP:	IN THE PREFERENCES MENU, YOU MUST SET THE STBY MODE TO NORMAL. IF YOU DO NOT CHANGE THIS SETTING, YOU WILL NOT BE ABLE TO TURN THE RECEIVER ON VIA RS232.		
CABLE DIAGRAM:	CNSP-123		


www.crestron.com



Certified Module

Partner: Marantz Model: SR9600 Device Type: Surround Receiver





CONTROL:

CONTROL:		
RX\$	S	Serial signal to be routed from a 2-way serial com port.
power_on/off/toggle	D	Pulse to turn the receiver on and off.
input_*	D	Pulse to select the input.
input_mode_cyclic/auto	D	Pulse to set the input mode.
input_*_fixed	D	Pulse to set the input type to digital fixed or analog fixed.
volume_up/down	D	Press and hold to adjust the volume.
audio_mute_on/off/toggle	D	Pulse to turn the volume mute on and off.
volume_value(-80d_to18d)	A	Analog signal to allow for direct volume level setting.
volume_set_direct	D	Pulse to set the volume to the level value on volume_value(-80d_to_18d) immediately.
volume_set_gradual	D	Pulse to set the volume to the level value on volume_value(-80d_to_18d) gradually.
attenuator_on/off/toggle	D	Pulse to turn the attenuator on and off.
bass/treble_up/down	D	Pulse to adjust the bass or treble.
video_mute_on/off/toggle	D	Pulse to turn the video mute on and off.
display_cyclic/input/level/auto_off/off	D	Pulse to set the receiver's front panel to input, surround, auto off, or off.

www.crestron.com





Certified Module

speaker_*_on/off/toggle	D	Pulse to turn speaker a or b on and off.
sleep_timer_off	D	Pulse to turn the sleep timer off.
sleep_timer_*min	D	Pulse to set the sleep timer for the desired number of minutes.
sleep_set_cyclic	D	Pulse to cycle the sleep timer.
osd_on/off/toggle	D	Pulse to turn the on screen display on and off.
night_mode_on/off/toggle	D	Pulse to turn the night mode on and off.
DC_trig1/2/3/4_on/off	D	Pulse to turn the DC trigger 1, 2, 3 or 4 on and off.
re-EQ_on/off/toggle	D	Pulse to turn the re-EQ on and off.
bilingual_main/sub/main+sub/cyclic	D	Pulse to set the bilingual mode.
setup_menu_on/off/toggle	D	Pulse to turn the set up menu on and off.
menu_cursor_enter/up/down/left/right	D	Pulse to control the cursor.
surrmode_change_next/prev	D	Pulse to go the next or previous surround mode.
surr*	D	Pulse to select the surround mode.
surrTHX_on/off/toggle	D	Pulse to turn the THX mode on and off.
dolby_HP_change	D	Pulse to select the Dolby headphone mode.
dolby_HP_*	D	Pulse to directly select the Dolby headphone mode.
test_tone_on/off/toggle	D	Pulse to turn the test tone mode on and off.
test_tone_channel_next/prev	D	Pulse to change the test tone oscillation channel.
channel_select_dispon/off/toggle	D	Pulse to turn the channel select display on and off.
lip_sync_off	D	Pulse to turn the lip sync adjustment off.
lip_sync_up/down	D	Pulse to adjust the lip sync delay by 10 msec.
tuner*_mode_auto_stereo/mono/toggle	D	Pulse to set the FM tuner to auto stereo or mono.

www.crestron.com







tuner*_freq_up/down	D	Press and hold to adjust the tuner frequency.
tuner*_auto_*	D	Pulse to start and stop the tuner auto tune function.
tuner*_preset_up/down	D	Pulse to step to the next or previous tuner preset.
tuner*_preset_scan_start/stop	D	Pulse to start and stop the tuner preset scan function.
tuner*_key*	D	Pulse to enter either the tuner frequency or tuner preset number. You must pulse the tuner_freq_num_direct_set input or the tuner_preset_num_call input.
tuner*_preset_num_call	D	Pulse to select the preset number entered using the tuner_key* inputs.
tuner*_freq_num_direct_set	D	Pulse to select the tuner frequency entered using the tuner_key* inputs.
tuner*_rds_disp(only_EU_Ver.)	D	Pulse to turn the rds on and off. Only available on European models.
tuner*_rds_pty(only_EU_Ver.)	D	Pulse to turn the rds pty function on and off. Only available on European models.
mr*_power_on/off_toggle	D	Pulse to turn the mutli-room power on and off.
ms*_power_on/off/toggle	D	Pulse to turn the multi-room speaker on and off.
mr*_input_*	D	Pulse to select the multi-room input.
mr*_volume_up/down	D	Press and hold to adjust the multi-room volume.
mr*_audio_mute_on/off/toggle	D	Pulse to turn the multi-room volume mute on and off.
mr*_osd_on/off	D	Pulse to turn the multi-room on screen display on and off.
mr*_sleep_timer_off	D	Pulse to turn the multi-room sleep timer off.
mr*_sleep_timer_*min	D	Pulse to set the multi-room sleep timer for the desired number of minutes.
mr*_sleep_set_cyclic	D	Pulse to cycle the sleep timer.
mr*_tuner*_mode_auto_stereo/mono/toggle	D	Pulse to set the multi-room FM tuner to auto stereo or mono.
mr*_tuner*_freq_up/down	D	Press and hold to adjust the multi-room tuner.
mr*_tuner*_auto_*	D	Pulse to start and stop the tuner auto tune function.
mr*_tuner*_preset_up/down	D	Pulse to step to the next or previous preset.

©2004 Crestron Electronics, Inc. 15 Volvo Drive • Rockleigh, NJ 07647 800.237.2041 / 201.767.3400 www.crestron.com





Certified Module

mr*_tuner*_preset_scan_start/stop	D	Pulse to start and stop the preset scan function.
mr*_tuner*_preset_num_call	D	Pulse to call the tuner preset number.
mr*_tuner*_freq_num_direct_set	D	Pulse to directly set the tuner frequency.
auto_status_on/off	D	Pulse to turn the auto status function on and off.

FEEDBACK: TX\$ S Serial signal to be routed to a 2-way serial com port. D power_on/off_fb High to indicate the current power state for the main zone. video_input_*_fb D High to indicate the currently selected video input. audio_input_*_fb D High to indicate the currently selected audio input. input_mode_analog/digital_autoselected_fb D High to indicate the currently auto selected input type. D High to indicate the currently manually selected input type. input_analog/digital_fixed_fb Analog value indicating the current volume level. To be displayed using a bar volume_bar A graph on a touch panel. Serial signal indicating the current volume level in dB. This is the same as the S volume\$ front panel of the receiver. audio mute on/off fb D High to indicate the current state of the volume mute. attenuator_on/off_fb D High to indicate the current state of the attenuator function. Analog values indicating the current bass or treble level. To be displayed using bass/treble_bar А bar graphs on a touch panel. Serial signal indicating the current bass and treble level. This is the same as the bass/treble\$ S front panel of the receiver. D High to indicate the current state of the video mute. video mute on/off fb D display_input/level/auto_off/off_fb High to indicate the currently selected front panel display mode. D speaker_*_on/off_fb High to indicate the current state for speakers a and b.







sleep_timer_off_fb	D	High to indicate that the sleep timer is off.
sleep_timer_bar	A	Analog value indicating the time remaining before the sleep mode will turn the receiver off. To be displayed using a bar graph on a touch panel.
sleep\$	s	Serial signal indicating the sleep time remaining.
osd_on/off_fb	D	High to indicate the current state of the on screen display.
night_mode_on/off_fb	D	High to indicate the current state of the night mode.
DC_trig1/2/3/4_on/off_fb	D	High to indicate the current state of the DC triggers 1, 2, 3 & 4.
re-EQ_on/off_fb	D	High to indicate the current state of the re-EQ.
bilingual_main/sub/main+sub_fb	D	High to indicate the current state of the bilingual function.
setup_menu_on/off_fb	D	High to indicate the current state of the setup menu.
surr*_fb	D	High to indicate the currently selected surround mode.
dolby_HP_*_fb	D	High to indicate the currently active headphone mode.
test_tone_on/off_fb	D	High to indicate the current state of the test tone.
test_tone_auto/manual_mode_fb	D	High to indicate the current test tone mode.
test_tone_ch_*_fb	D	High to indicate the current channel of test tone.
channel_select_dispon/off_fb	D	High to indicate the current state of the channel select display.
lip_sync_off_fb	D	High to indicate that the lip sync function is currently off.
lip_sync_bar	A	Analog value indicating the current lip sync delay. To be displayed using a bar graph on a touch panel.
lip_sync\$	S	Serial signal indicating the current lip sync delay.
tuner*_stereo/mono_fb	D	High to indicate the current stereo/mono mode of the tuner.
tuner*_frequency_fm	A	Analog value indicating the currently tuned FM channel. To be display using a digital gauge in the format XXX.XX.
tuner*_frequency_am	A	Analog value indicating the currently tunes AM channel. To be displayed using a digital gauge in the format XXXX.

©2004 Crestron Electronics, Inc. 15 Volvo Drive • Rockleigh, NJ 07647 800.237.2041 / 201.767.3400 www.crestron.com



Certified Module



tuner*_freq.\$	S	Serial signal indicating the current tuner frequency.
tuner*_preset_number	A	Analog value indicating the currently selected tuner preset number.
tuner*_keyin_value	A	Analog value indicating the current value entered using the tuner_key* inputs.
mr*_power_on/off_fb	D	High to indicate the current power state of the multi-room zone.
ms*_power_on/off_fb	D	High to indicate the current power state of the multi-room speaker.
mr*_video_input_*_fb	D	High to indicate the currently selected video input for the multi-room zone.
mr*_audio_input_*_fb	D	High to indicate the currently selected audio input for the multi-room zone.
mr*_volume_bar	A	Analog value indicating the current volume level for the multi-room zone. To be displayed using a bar graph on a touch panel.
mr*_volume\$	S	Serial signal indicating the current volume level for the multi-room zone. This is the same as on the front panel of the receiver.
mr*_audio_mute_on/off_fb	D	High to indicate the current state of the multi-room volume mute.
mr*_volume_variable/fixed_fb	D	High to indicate whether the multi-room volume is variable or fixed.
mr*_osd_on/off_fb	D	High to indicate the current state of the multi-room zone on screen display.
mr*_sleep_timer_off_fb	D	High to indicate that the multi-room sleep timer is off.
mr*_sleep_timer_bar	A	Analog value indicating the time remaining before the sleep mode will turn the multi-room zone off. To be displayed using a bar graph on a touch panel.
mr*_sleep\$	S	Serial signal indicating the sleep time remaining for the multi-room zone.
mr*_tuner*_stereo/mono_fb	D	High to indicate the current multi-room tuner stereo/mono mode.
mr*_tuner*_frequency_fm	A	Analog value indicating the currently tuned FM channel for the multi-room tuner. To be display using a digital gauge in the format XXX.XX.
mr*_tuner*_frequency_am	A	Analog value indicating the currently tunes AM channel for the multi-room tuner. To be displayed using a digital gauge in the format XXXX.
mr*_tuner*_freq.\$	S	Serial signal indicating the current tuner frequency.
mr*_tuner*_preset_number	A	Analog value indicating the currently selected tuner preset number for the multi- room tuner.

www.crestron.com







tuner*_busyfb	D	High to indicate that the selected tuner is busy.
auto_status_on/off_fb	D	High to indicate the current state of the auto status function.
signal_*_fb	D	High to indicate the type of digital audio signal received.
sampling_*_fb	D	High to indicate the sampling rate of the received digital signal.
ch_status_*_fb	D	High to indicate the active channels for the received digital signal.

TESTING:	
OPS USED FOR TESTING:	PRO2: 3.137
COMPILER USED FOR TESTING:	2.06.20
SAMPLE PROGRAM:	Marantz SR9600 Demo PRO2
REVISION HISTORY:	V. 1.0