





GENERAL INFORMATION		
SIMPLWINDOWS NAME:	Sony STR-DA5600ES IP v1.1	
CATEGORY:	Receiver/Processor	
VERSION:	1.1	
SUMMARY:	Controls power, volume, input select and surround mode select, and displays true feedback via TCP/IP.	
GENERAL NOTES:	This module will control all available TCP/IP functions on a Sony STR-DA5600ES AV surround receiver. Discrete power on/off, volume adjust/mute, input select, and surround mode select functions are included. True feedback is provided for power state, input selected, surround mode status, and volume status. The Sony STR-DA5600ES surround sound receiver is a three-zone receiver. The	
	receiver can accept commands every 100ms. The zones on this module are referred to Main, Zone_2 and Zone_3.	
	The zones are independently controllable. Only the Main zone's volume level will be displayed on the receiver's front panel. Surround modes are only selected for the Main zone. The Main zone has all input selections available to it. Zones 2 and 3 cannot select the multi-channel inputs, or the Phono input. The user may set Zone 2 or 3 to select the same input as the Main zone by selecting the "Source" input.	
	The tuner has two tuning modes: Auto and Manual. Auto tuning mode is the default setting. When in Auto tuning mode, a "Tune_Stop" button is necessary for proper operation of the auto tuning functions. Manual tuning mode does not use the "Tune_Stop" button. When using the tuner in auto tuning mode the receiver is polled continuously. Some feedback will disappear during the tuning up or down. The feedback will return after "Tune Stop" is pressed.	
	The unit will be polled for it's status after any function is triggered on this module. If it is desired to poll the unit at other times, you can assert the Poll_Enable input. This will cause the unit to be polled every 60 seconds.	
	Note that for controlling the receiver's 12V trigger, the 12V trigger on the STR-DA5600ES has to be set for Network control.	
CRESTRON HARDWARE REQUIRED:	C2NENET-1, C2NENET-2	
SETUP OF CRESTRON HARDWARE:	TCP/IP Port 6001d.	
VENDOR FIRMWARE:	Software Version 0.281	
VENDOR SETUP:	Serial control must be enabled by going into the Sony On-Screen Menu, selecting Settings->Network->External Control and set to "ON".	
CABLE DIAGRAM:	N/A	



# **Certified Module**



CONTROL:		
Main_Power_ <on off="" toggle=""></on>	D	Pulse to send power commands for main zone.
Zone_2_Power_ <on off="" toggle=""></on>	D	Pulse to send power commands for zone 2.
Zone_3_Power_ <on off="" toggle=""></on>	D	Pulse to send power commands for zone 3.
Main_12V_Trigger_ <on off="" toggle=""></on>	D	Pulse to send commands to control the main zone 12V trigger.
Zone_2_12V_Trigger_ <on off="" toggle=""></on>	D	Pulse to send commands to control the zone 2 12V trigger.
Zone_3_12V_Trigger_ <on off="" toggle=""></on>	D	Pulse to send commands to control the zone 3 12V trigger.
Main_Input_*	D	Pulse to select input for main zone.
Zone_2_Input_*	D	Pulse to select input for zone 2.
Zone_3_Input_*	D	Pulse to select input for zone 3.
Main_Vol_ <up down=""></up>	D	Press to adjust main zone volume level.
Main_Vol_Mute_ <on off=""></on>	D	Pulse to turn main zone mute on or off.
Zone_2_Vol_*	D	Press to adjust zone 2 volume level.
Zone_2_Vol_Mute_ <on off=""></on>	D	Pulse to turn zone 2 mute on or off.
Surround_*	D	Pulse to select the desired surround mode.
Tune_*	D	Pulse to trigger tuner control functions.
Control_ <am fm="" sirius="" xm="">_Tuner</am>	D	Pulse to select the tuner to be controlled.
Preset_ <up dn=""></up>	D	Pulse to scroll up or down through Sirius or XM presets.
Category_ <up dn=""></up>	D	Pulse to scroll through the available Sirius or XM categories.
Category_Mode	D	Pulse to select Sirius or XM category "All" or "One".
Key_*	D	Pulse these signals to directly select a Sirius/XM/AM/FM channel or frequency.
Preset_*	D	Pulse to send the preset selected command for Sirius/XM/AM/FM, and requests the preset name. NOTE: For AM/FM tuner, only presets 1-10 can be recalled. XM/Sirius can recall presets 1-30.
GUI_Toggle	D	Pulse to enable or disable GUI mode.

©2004 Crestron Electronics, Inc. 15 Volvo Drive • Rockleigh, NJ 07647 800.237.2041 / 201.767.3400 www.crestron.com

# CRESTRON

# Partner: Sony Model: STR-DA5600ES Device Type: AV Receiver



**Certified Module** 

Menu	D	Pulse to enable/disable menu.
Display	D	Press to display the current status of the receiver. While in GUI mode, this will display the menu on the TV screen.
Cursor_ <up down="" left="" right=""></up>	D	Pulse to select menu items.
Enter	D	Pulse to enter the menu item that was selected by pulsing the Cursor_ <up down="" left="" right=""> signals.</up>
Return	D	Pulse to return to the previous menu while the menu is displayed.
Option	D	Pulse to display and select items from option menus if available.
Quickclick	D	Use to control components or lighting connected to the receiver.
HDMI_Out_ <a a+b="" b=""></a>	D	Pulse to select the HDMI output.
Poll_Enable	D	Polls the receiver for input, volume level, volume mute, power, tuner frequency, tuner band, preset number, preset name, surround mode, and 12v trigger, for all zones
{{TCP/IP_Client_>>_Connect-F}}	D	To be connected to the "Connect_F" input on the TCP/IP client definition.
{{TCP/IP_Client_>>_status}}	A	To be connected to the "status" input on the TCP/IP client definition that will be communicating with the unit being controlled.
{{TCP/IP_Client_>>_RX\$}}	S	To be connected to the "RX\$" input on the TCP/IP client definition that will be communicating with the unit being controlled.

FEEDBACK:		
Main_Power_Is_ <on off=""></on>	D	Indicates main zone power status.
Zone_2_Power_Is_ <on off=""></on>	D	Indicates zone 2 power status.
Zone_3_Power_Is_ <on off=""></on>	D	Indicates zone 3 power status.
Main_12V_Trigger_Is_ <on off=""></on>	D	Indicates main zone 12V trigger status.
Zone_2_12V_Trigger_Is_ <on off=""></on>	D	Indicates zone 2 12V trigger status.
Zone_3_12V_Trigger_Is_ <on off=""></on>	D	Indicates zone 3 12V trigger status.
Main_Input_Is_*	D	Indicates input selected for main zone.
Zone_2_Input_Is_*	D	Indicates input selected for zone 2.

www.crestron.com





Integrated Partner

Zone_3_Input_Is_*	D	Indicates input selected for zone 3.
Main_Vol_Gauge	А	Indicates main volume value for gauge on touchpanel.
Main_Vol_Mute_Is_ <on off=""></on>	D	Indicates main volume mute status.
Zone_2_Vol_Gauge	А	Indicates zone 2 volume value for gauge on touchpanel.
Zone_2_Vol_Mute_Is_ <on off=""></on>	D	Indicates zone 2 volume mute status.
Surround_ls_*	D	Indicates surround mode selected.
Freqency_Request	А	Value displaying direct channel/frequency being requested.
Frequency_Current	А	Indicates frequency selected.
Tune_ <manual auto="">_Active</manual>	D	Indicates tuner manual or auto status.
Tuning_ <up down=""></up>	D	Indicates tuner searching up or down.
Tune_ <am fm="">_Active</am>	D	Indicates terrestrial tuner in AM or FM mode.
Preset_ls_*	D	Indicates currently selected Sirius/XM/AM/FM preset.
Preset_Number_Text	S	Displays currently selected Sirius/XM/AM/FM preset number.
Preset_Name_Text	S	Displays currently selected Sirius/XM/AM/FM preset name.
XM_*	D	XM status feedback.
XM_*_Text	S	Displays XM current Channel/Category/Artist/Song Title information.
Sirius_*	D	Sirius status feedback.
Sirius_*_Text	S	Displays Sirius current Channel/Category/Artist/Song Title/Composer information.
Connected	D	High to indicate that there is an IP connection to the unit.
Connection_Status_Text	S	Indicates the current IP connection status to the unit.
{{Connect_>>_TCP/IP_Client}}	D	To be connected to the "Connect" output on the TCP/IP client definition that will be communicating with the unit being controlled.
{{TX\$_>>_TCP/IP_Client}}	S	To be connected to the "TX\$" output on the TCP/IP client definition that will be communicating with the unit being controlled.

www.crestron.com







TESTING:	
OPS USED FOR TESTING:	v4.001.1012
SIMPL WINDOWS USED FOR TESTING:	v2.12.39
DEVICE DB USED FOR TESTING:	v27.05.003.00
CRES DB USED FOR TESTING:	v21.05.007.00
SYMBOL LIBRARY USED FOR TESTING:	v664
SAMPLE PROGRAM:	Sony STR-DA5600ES IP v1.1 Demo PRO2.smw
REVISION HISTORY:	v1.1 – Original release.