



Manufacturer: World Wide Programming B.V.
Model: WWP Airco Bus v1.0
Device Type: Software module - WWP Home Config

CONTACT SUPPORT: (please fill out carefully)

COMPANY NAME:	World Wide Programming B.V.
SUPPORT CONTACT:	Leonel Geagea
EMAIL ADDRESS:	info@worldwideprogramming.nl
PHONE:	+31 6 1512 5959
ADDRESS:	Rotterdam, the Netherlands
NOTES:	Website: https://www.worldwideprogramming.nl . Support in English and Dutch; please include the processor model, firmware and the Status / License_Status text of WWP Core.

GENERAL INFORMATION

SIMPLWINDOWS NAME:	WWP Airco Bus v1.0
CATEGORY:	HVAC
VERSION:	1.0
SUMMARY:	Connects WWP Home Config to air-conditioning units: power, fan speed and mode per unit, with optional feedback.
GENERAL NOTES:	One instance per hardware block (more instances with a different Hw_Offset for larger systems). Feedback inputs are optional: without feedback the module assumes a command succeeded; with feedback, the feedback wins. Both pulses (Power_On / Power_Off) and a latching Power[n] output are available. Fan: 1 auto, 2 low, 3 mid, 4 high. Mode: 1 auto, 2 cool, 3 heat. Requirements: WWP Core (once per program) and the SIMPL# library WwpConfig.clz in the same folder as the program. All WWP modules communicate with each other inside the processor; no extra wiring between modules is needed. Start-up: the module does not send any commands to devices at boot. After the configuration is loaded it only publishes the current state (names, visibility, feedback) so panels and logic are correct straight away. Licensing: part of the commercial WWP Home Config package (licenses S / M / L, 7-day trial per processor). See "WWP Home Config v1.0 Help.pdf" for the complete system description.
CRESTRON HARDWARE REQUIRED:	4-Series control system (developed and tested on RMC4). 3-Series is not



Manufacturer: World Wide Programming B.V.
 Model: WWP Airco Bus v1.0
 Device Type: Software module - WWP Home Config

	supported.
SETUP OF CRESTRON HARDWARE:	4-Series control system. Copy WwpConfig.clz next to the .smw program, add WWP Core once, then add the WWP modules you need. Load the program, open the web configuration (http://<processor-ip>:8090/) and enter the rooms, devices and panels.
VENDOR FIRMWARE:	N/A - software module (no third-party device).
VENDOR SETUP:	In the web configuration: Rooms > Airco - hw, available fan speeds and modes, favourite in the climate overview.
CABLE DIAGRAM:	N/A - logic module, no device connection.

CONTROL:

<u>Signal/Function Name</u>	<u>D,S,A</u> <u>Digital, Serial, Analog signal property - description</u>
Power_Fb[1-100]	D High = airco n is on (optional).
Fan_Fb[1-100]	A Fan speed of airco n: 1 auto, 2 low, 3 mid, 4 high (optional).
Mode_Fb[1-100]	A Mode of airco n: 1 auto, 2 cool, 3 heat (optional).

FEEDBACK:

Power_On[1-100]	D Pulse: airco n on.
Power_Off[1-100]	D Pulse: airco n off.
Power[1-100]	D Latching: high = airco n on.
Fan[1-100]	A Requested fan speed: 1 auto, 2 low, 3 mid, 4 high.
Mode[1-100]	A Requested mode: 1 auto, 2 cool, 3 heat.



CRESTRON®

HELP FILE DOCUMENT

Model: WWP Airco Bus v1.0

Device Type: Software module - WWP Home Config

PARAMETERS:

Hw_Offset	A 0 = airco hw 1-100, 100 = hw 101-200 ...
------------------	---

TESTING: (please fill out carefully)

OPS USED FOR TESTING: RMC4 - firmware 2.8005.00031

SIMPL WINDOWS USED FOR TESTING: 4.3200.02.01

DEVICE DB USED FOR TESTING: 200.470.001.00

CRES DB USED FOR TESTING: 228.60.002.00

SYMBOL LIBRARY USED FOR TESTING: 1244

SAMPLE PROGRAM: WWP Software-InterfaceDemo (touch panel: WWPIInterfaceDemo_v1.ch5z,
contract WWPIInterfaceDemo.chd)

REVISION HISTORY: v1.0 - initial release.