

Partner: Biamp
Model: Tesira
Device Type: Digital Signal Processor



GENERAL INFORMATION

SIMPLWINDOWS NAME:	Biamp Tesira State Control v3.2
CATEGORY:	DSP
VERSION:	3.2
SUMMARY:	This module controls most mute/state points in the Biamp Tesira.
GENERAL NOTES:	<p>This Biamp Tesira State Control v3.2 module is used to control a wide variety of control objects within the Biamp Tesira. This module's parameters need to be setup correctly in order to control the state object that you wish to control. So understanding what your state object requires is important to the settings of this module.</p> <p>The following are required.</p> <p>Instance_Tag: Instance_Tag is the unique name that was assigned inside the Biamp Tesira Programming.</p> <p><i>Note: If your Instance_Tag has spaces in its name, surround the name with quotes using the \x22 hex escape sequence. Example: \x22My Name\x22</i></p> <p>Attribute_Code: Attribute_Code selection informs the module what type of state to control. This is required since some Biamp Tesira objects having multiple state control points. The choices are Mute, InputMute, OutputMute, CrossPointLevelState, Crosspoint, ChannelMute, MuteIn, MuteOut, MuteSource, WallState, State, Connected, HostMasterMute, HostMute, Streaming, EmbeddedAudioMute, VideoMute, VideoFreeze and AuxMute. If the object that you wish to control contains one of these control attribute codes, then this module will control that object.</p> <p>The following maybe optional.</p> <p>Index_1: When controlling a Biamp Tesira object, part of the control protocol may use Index_1. When Index_1 is not required, the parameter needs to be set to 0.</p> <p>Index_2: When controlling a Biamp Tesira object, part of the control protocol may use Index_2. When Index_2 is not required, the parameter needs to be set to 0.</p> <p>Index_1 in most cases represents the input value, and Index_2 represents the output value. So when dealing with things like Crosspoints, both Index_1 and Index_2 are required. Understanding the Biamp Tesira control object is mandatory in order to setup this module correctly.</p> <p>During initialization of the module, it will automatically try to figure out based on the Instance_Tag what type of Biamp Tesira control object you are attempting to control. Once it acquires the identification, it will request only the appropriate state information from the Biamp Tesira control object. If it was not able to figure out the type of control object, it will send queries based on a standard list. In this case you may get some errors back from the Biamp Tesira indicting the commands are not supported. This is normal, but if ALL commands are returned with errors, then your Instance_Tag may be incorrect or not currently configured.</p>
CRESTRON HARDWARE REQUIRED:	3-series & 4-series processors only (Note: use 1.X modules for 2-series processors)

Partner: Biamp
Model: Tesira
Device Type: Digital Signal Processor

**GENERAL INFORMATION** *continued*

SETUP OF CRESTRON HARDWARE:	This module requires the Biamp Tesira Command Processor IP v3.2 or the Biamp Tesira Command Processor RS232 v3.2 modules in order to operate. Please read the help files associated with these modules.
VENDOR FIRMWARE:	Tesira Firmware - 3.16.0.27

Partner: Biamp
Model: Tesira
Device Type: Digital Signal Processor

**PARAMETER:**

Instance_Tag	<p>Instance_Tag is the unique name, for the control object, that was assigned inside the Biamp Tesira Programming.</p> <p><i>Note: If your Instance_Tag has spaces in its name, surround the name with quotes using the \x22 hex escape sequence. Example: \x22My Name\x22</i></p>
Attribute_Code	<p>Attribute_Code selection informs the module what type of state to control. This is required since some Biamp Tesira objects having multiple state control points. The choices are Mute, InputMute, OutputMute, CrossPointLevelState, Crosspoint, ChannelMute, MuteIn, MuteOut, MuteSource, WallState, State, Connected, HostMasterMute, HostMute, Streaming, EmbeddedAudioMute, VideoMute, VideoFreeze and AuxMute. If the object that you wish to control contains one of these control attribute codes, then this module will control that object.</p>
Index_1	<p>When controlling a Biamp Tesira object, part of the control protocol may use Index_1. When Index_1 is not required, the parameter needs to be set to 0.</p> <p>Index_1 in most cases represents the input value, and Index_2 represents the output value. So when dealing with things like Crosspoints, both Index_1 and Index_2 are required. Understanding the Biamp Tesira control object is mandatory in order to setup this module correctly.</p>
Index_2	<p>When controlling a Biamp Tesira object, part of the control protocol may use Index_2. When Index_2 is not required, the parameter needs to be set to 0.</p> <p>Index_1 in most cases represents the input value, and Index_2 represents the output value. So when dealing with things like Crosspoints, both Index_1 and Index_2 are required. Understanding the Biamp Tesira control object is mandatory in order to setup this module correctly.</p>
Command_Processor_ID	<p>Setting to indicate the ID for the command processor that this module will register itself with.</p>

Partner: Biamp
Model: Tesira
Device Type: Digital Signal Processor

**CONTROL:**

Poll_State	D	Pulse to poll for the current value. If the control object that you are controlling has been able to successfully register a subscription, then this signal may not do anything. A subscription is a process of registering for unsolicited messages. Some Biamp Tesira control objects have this capability.
State_On, State_Off, State_Toggle	D	Pulse to change state of the control object.
Enable	D	Set High: Control Module Enabled. Set Low: Control Module Disabled. <i>Note: Use a 1 for normal operation.</i>

Partner: Biamp
Model: Tesira
Device Type: Digital Signal Processor

**FEEDBACK:**

Is_Initialized	D	Signal is high to indicate the module has successfully received all required responses from its initializing queries.
State_Is_On, State_Is_Off	D	Indicates the current state status.
Is_Quarantined	D	Signal is high to indicate that a component has failed to initialize because of configuration issues. The Command Processor will attempt to initialize the quarantined component again when a new connection has been established.

Partner: Biamp
Model: Tesira
Device Type: Digital Signal Processor

**TESTING:**

OPS USED FOR TESTING:	CP3: v1.603.4242.34642
SIMPL WINDOWS USED FOR TESTING:	4.14.21
CRES DB USED FOR TESTING:	201.05.001.00
DEVICE DATABASE:	200.10.001.00
SYMBOL LIBRARY USED FOR TESTING:	1115
SAMPLE PROGRAM:	Biamp Tesira v3.2 IP Demo Biamp Tesira v3.2 RS232 Demo
REVISION HISTORY:	v2.0 – Initial Release v2.1 – No revisions have been performed. v2.2 – Added the options AudioMute, VideoMute and VideoFreeze to the list of supported attribute codes. v3.0 – Added SIMPL# event callbacks. Reworked module Registration, and added Enable signal. v3.1 – Added quarantine functionality. v3.2 – No revisions have been performed.