

Partner: Integra  
 Model: DBS-30.2  
 Device Type: Blu-ray Player



### GENERAL INFORMATION

SIMPLWINDOWS NAME	Integra DBS-30.2 IP v1.0
CATEGORY	DVD/Blu-ray
VERSION	1.0
SUMMARY	This module provides control and true feedback for the Integra DBS-30.2 DVD/Blu-ray player.
GENERAL NOTES	This module will control the DBS-30.2 DVD/Blu-ray player. It should also control the DBS-50.2 DVD/Blu-ray player.  <b>NOTE: THIS MODULE IS 2-SERIES ONLY.</b>
CRESTRON HARDWARE REQUIRED	C2ENET-1, C2ENET-2
SETUP OF CRESTRON HARDWARE	N/A
VENDOR FIRMWARE	N/A
VENDOR SETUP	Ethernet control within the Advanced settings must be enabled in order for Ethernet port to be active when unit is off.
CABLE DIAGRAM	N/A

### CONTROL

Connect	D	Hold high to connect to player.
Power_On	D	Pulse to turn the power on.
Power_Off	D	Pulse to turn the power off.
Power_Toggle	D	Pulse to toggle the power on/off.
Play	D	Pulse to play the disc.
Pause	D	Pulse to pause the disc.

**Partner: Integra**  
**Model: DBS-30.2**  
**Device Type: Blu-ray Player**



<b>Stop</b>	D	Pulse to stop the disc.
<b>Next_Track</b>	D	Pulse to skip to the next track.
<b>Previous_Track</b>	D	Pulse to skip to the previous track.
<b>Scan_Forward</b>	D	Pulse to scan forward.
<b>Scan_Reverse</b>	D	Pulse to scan backwards.
<b>Up_Arrow</b>	D	Pulse to move the selection up
<b>Down_Arrow</b>	D	Pulse to move the selection down.
<b>Left_Arrow</b>	D	Pulse to move the selection left.
<b>Right_Arrow</b>	D	Pulse to move the selection right.
<b>Enter</b>	D	Pulse to send enter command.
<b>Return</b>	D	Pulse to send return command.
<b>Home</b>	D	Pulse to send home command.
<b>Menu</b>	D	Pulse to show the menu.
<b>Title</b>	D	Pulse to show the title screen.
<b>Display</b>	D	Pulse to display stream info.
<b>Angle</b>	D	Pulse to change the angle.
<b>Audio</b>	D	Pulse to change the audio.
<b>Subtitle</b>	D	Pulse to change the subtitle.
<b>Key_*</b>	D	Pulse to send corresponding digit.

**Partner: Integra**  
**Model: DBS-30.2**  
**Device Type: Blu-ray Player**



Search	D	Pulse to begin a search.
Repeat	D	Pulse to repeat.
A-B_Repeat	D	Pulse to set an A-B repeat.

## FEEDBACK

Player_Is_Connected	D	High to indicate that the player is connected.
Power_Is_*	D	High to indicate current power state.
Player_Is_*	D	High to indicate current player state.
Current_Disc_Type_Text	S	Serial signal to indicate the type of disc currently inserted.
Current_Title_Text	S	Serial signal to indicate the current disc title.
Current_Chapter_Text	S	Serial signal to indicate the current chapter text.
Current_Elapsed_Time_Text	S	Serial signal to indicate the current elapsed playback time.

## TESTING

OPS USED FOR TESTING	v4.001.1012
SIMPL WINDOWS USED FOR TESTING	V3.01.24
CRESTRON DATABASE USED FOR TESTING	v24.00.039.00
DEVICE DATABASE USED FOR TESTING	v32.00.019.00
SAMPLE PROGRAM	Integra DBS-30.2 IP v1.0 Demo PRO2.smw
REVISION HISTORY	V1.0 – Initial release.