




Partner: Meridian

Model: G98 DVD Player

Device Type: Transport Decks



GENERAL INFORMATION			
SIMPLWINDOWS NAME:	Meridian G98 DVD Player		
CATEGORY:	Transport Decks		
VERSION:	1.0		
SUMMARY:	This module controls the Meridian G98 DVD Player. It does not provide feedback.		
GENERAL NOTES:	This module will control the Meridian G98 DVD Player. It does not provide feedback due to limitations of the DVD Player.		
CRESTRON HARDWARE REQUIRED:	CNX-COM, CNX-COM2, C2-COM, C2-COM2, C2-COM3, ST-COM		
SETUP OF CRESTRON HARDWARE:	RS232 Baud: 9600 Parity: None Data Bits: 8 Stop Bits: 1		
VENDOR FIRMWARE:	None		
VENDOR SETUP:	None		
CABLE DIAGRAM:	CNSP-124		







Partner: Meridian Model: G98 DVD Player Device Type: Transport Decks



CONTROL:		
Play	D	Pulse to play the disc.
Stop	D	Pulse to stop the disc.
Pause	D	Pulse to pause the disc.
Fast_Forward	D	Pulse to cycle through the Fast Forward speeds.
Fast_Back	D	Pulse to cycle through the Fast Back speeds.
Next_Chapter/Track	D	Pulse to jump to the next chapter or track.
Previous_Chapter/Track	D	Pulse to go back to the previous chapter or track.
Tray_Open/Close	D	Pulse to open and close the tray.
Repeat	D	Pulse to turn the chapter/track repeat on and off.
AB_Repeat	D	Pulse to cycle through the AB repeat modes.
Subtitle_On/Off	D	Pulse to turn the subtitles on and off.
Subtitle_Cycle	D	Pulse to cycle through the subtitle languages.
Angle	D	Pulse to activate the angle function.
Audio	D	Pulse to cycle through the different audio languages.
Menu_*	D	Pulse to navigate through the menus.
Key_*	D	Pulse to enter the chapter or track number to jump to. YOU MUST PULSE Menu_Enter AFTER THE KEY NUMBERS>

FEEDBACK:		
To_Device\$	S	Serial signal to be routed to a serial com port.





Partner: Meridian Model: G98 DVD Player

Device Type: Transport Decks



TESTING:	
OPS USED FOR TESTING:	PRO2: 3.137 CNMSX-Pro: 5.14.02x
COMPILER USED FOR TESTING:	2.05.22
SAMPLE PROGRAM:	Meridian G98 DVD Player Demo
REVISION HISTORY:	V. 1.0