

SIMPLWINDOWS NAME: Navitar X-ray Presenter Model 140
CATEGORY: Other
VERSION: 1.0
SUMMARY: Control all standard functions on Navitar X-ray Presenter Model 140
GENERAL NOTES: None
CRESTRON HARDWARE REQUIRED: ST-COM, CNXCOM
SETUP OF CRESTRON HARDWARE: Baud Rate - 9600
Parity - None
Data Bits - 8
Stop Bits - 2
VENDOR FIRMWARE: None
VENDOR SETUP: Set unit to address 2 if applicable
CABLE NUMBER: CNSP-121

CONTROL:

HOME	D	Send the unit to the home position
ZOOM-IN/OUT	D	Zoom in or out accordingly
FOCUS-IN/OUT	D	Focus in or out accordingly
IRIS-OPEN/CLOSE	D	Open or close iris accordingly
MOVE-*	D	Move the lens around the X-ray in any standard or diagonal direction
LANDSCAPE/PORTRAIT	D	Orient the image accordingly
PRESET-1-16	D	Select any of the 16 presets on a 4x4 X-ray grid

FEEDBACK:

NAVITAR-TX\$	S	Select any of the 16 presets on a 4x4 X-ray grid
---------------------	---	--

OPS USED FOR TESTING: 3.16.08
COMPILER USED FOR TESTING: SimplWindows Version 1.20.04
SAMPLE PROGRAM: NAVTSTD
REVISION HISTORY: None