




| GENERAL INFORMATION | | | |
|-----------------------------|---|--|--|
| SIMPLWINDOWS NAME: | Panasonic PT-FW300NT v1.1 | | |
| CATEGORY: | TV/Video Projector | | |
| VERSION: | 1.1 | | |
| SUMMARY: | This module will control and/or report Power, Source Select, Picture Mode, Aspect, AV Mute, Freeze, Index Windows, No Signal Timeout, Picture Control and elapsed Lamp Hour usage via RS-232. | | |
| GENERAL NOTES: | This module will control the Panasonic PT-FW300NT. Although this module has been tested with the PT-FW300NT, it should also control the following projectors: PT-FW300 PT-F300NT PT-F300 NOTE: This module depends on feedback from the device. You cannot comment out the From_Device. This module is System Builder compatible. | | |
| CRESTRON HARDWARE REQUIRED: | X-Series Processor, CNX-COM2, ST-COM, 2-Series Processor, C2COM3 | | |
| SETUP OF CRESTRON HARDWARE: | RS232 Baud: 9600 Parity: N Data Bits: 8 Stop Bits: 1 | | |
| VENDOR FIRMWARE: | Unknown | | |
| VENDOR SETUP: | None | | |
| CABLE DIAGRAM: | CNSP-121 | | |









| CONTROL: | | |
|---|---|---|
| Power_ <on off="" toggle=""></on> | D | Pulse to turn power on or off. |
| Input_* | D | Pulse to select input. |
| Picture_Mode_* | D | Pulse to select picture mode. |
| Aspect_* | D | Pulse to select aspect. Some aspects may not be available depending on the input being displayed. |
| AV_Mute_ <on off="" toggle=""></on> | D | Pulse to enable or disable the AV mute. |
| Freeze_ <on off="" toggle=""></on> | D | Pulse to turn freeze mode on or off. |
| No_Signal_Shut_Off_*_Min | D | Pulse to set or disable the no signal shut off timeout value. |
| Auto_Setup | D | Pulse to trigger the auto setup function. |
| <menu down="" enter="" left="" right="" up=""></menu> | D | Pulse to navigate/select on screen menu items. |
| Default | D | Pulse to select default settings. |
| Index_Window | D | Pulse to enable or disable index window function. |
| Side_By_Side | D | Pulse to enable or disable side by side mode. |
| Brightness_ <up down=""></up> | D | Press to adjust brightness. |
| Contrast_ <up down=""></up> | D | Press to adjust contrast. |
| Volume_ <up down=""></up> | D | Press to adjust volume. |
| Closed_Caption_ <on off="" toggle=""></on> | D | Press to set or toggle closed caption feature. |
| Poll_En | D | Latch high to enable constant polling. |
| From_Device | S | Serial information returned via an RS-232 port. |







| FEEDBACK: | | |
|-------------------------------------|---|---|
| Power_Is_ <on off=""></on> | D | Indicates the current power state. |
| Lamp_* | D | Indicates the current lamp status. |
| Input_ls_* | D | Indicates the currently selected input. |
| Picture_Mode_Is_* | D | Indicates the current picture mode. |
| Aspect_ls_* | D | Indicates the current aspect ratio. |
| AV_Mute_Is_ <on off=""></on> | D | Indicates the current AV mute status. |
| Freeze_Is_ <on off=""></on> | D | Indicates the freeze mode status. |
| No_Signal_Shut_Off_Is_*_Min | D | Indicates the no signal shut off setting. |
| Lamp_Hours | Α | Diplays the lamp hours. |
| Brightness_Gauge | Α | Indicates the current brightness setting. |
| Contrast_Gauge | Α | Indicates the current contrast setting. |
| Volume_Gauge | Α | Indicates the current volume setting. |
| Filter_Advance | Α | Indicates the current status of advanced changed filter usage |
| Filter_Remaining_Time | Α | Indicates the current status of elapsed filter hour usage. |
| Closed_Caption_Is_ <on off=""></on> | D | Indicates the closed caption status. |
| To_Device | S | Serial information sent via an RS-232 port. |







| TESTING: | |
|----------------------------------|---|
| OPS USED FOR TESTING: | v4.001.1012 |
| SIMPL WINDOWS USED FOR TESTING: | v4.01.10 |
| DEVICE DB USED FOR TESTING: | v47.05.005.00 |
| CRES DB USED FOR TESTING: | v36.05.015.00 |
| SYMBOL LIBRARY USED FOR TESTING: | 850 |
| SAMPLE PROGRAM: | Panasonic PT-FW300NT v1.1 Demo PRO2 Panasonic PT-FW300NT v1.1 Demo MC3 |
| REVISION HISTORY: | v1.1 -adds Filter Advance/Expiration and Closed Caption |