

ANALOG WAY LIVECORE

Module: MASTER PRESETS

Crestron 2-series & 3-series

Date: **Marc 06, 2014**
Driver version: **V1.01**
Tested with: **LiveCore Firmware v01.02.x and v01.03.x**

GENERAL

This is an optional module for LiveCore series control.
It has been designed for feedback status of frames and logos as:

- Validity
- Recall for Main and Preview
- Feedback

CONNECTION

This module has to be connected to LiveCore_Main module.

Control

Inter_connect_Modules

| | | |
|------------------------|-------------|--|
| From_Module_Main | String_in | To be connected to LiveCore_Main module |
| Input_Refresh_All | Digital_in | Pulse for module initialization |
| To_Module_Main | String_out | To be connected to LiveCore_Main module |
| Message_Txt | String_out | LiveCore_Master_Preset module text status To be connected to LiveCore_Main module |
| Refresh_In_Progress_FB | Digital_out | Module status refresh in progress |
| Refresh_All_os | Digital_out | To be connected to next module for daisy chain initialization |
| NB_Screen_Available_FB | Ana_in | Number of Screen available feedback (from LiveCore_Main module) |

General

| | | |
|---------------------------------|-------------|--|
| Master_Preset_Main_Preset | Ana_in | Recall Master Preset X for Main (on change) |
| Master_Preset_Preview_Preset | Ana_in | Recall Master Preset X for Preview (on change) |
| Master_Preset>Loading_FB | Digital_out | Master Preset loading status |
| Master_Preset_Main_Preset_FB | Ana_out | Last recalled Master Preset for Main |
| Master_Preset_Preview_Preset_FB | Ana_out | Last recalled Master Preset for Preview |

Screen_Enable

X is the screen number (1=>8)

| | | |
|------------------------------------|-------------|-------------------------------------|
| M_Preset_For_ScreenX_Ena_PB | Digital_in | Enable Master Preset for screen X |
| M_Preset_For_ScreenX_Dis_PB | Digital_in | Disable Master Preset for screen X |
| M_Preset_For_ScreenX_Ena_Statut_FB | Digital_out | Master Preset validity for screen X |