

Partner: Cisco
Model: SX80
Device Type: Codec




GENERAL INFORMATION

SIMPLWINDOWS NAME:	Cisco Touch 10 Room Control Processor v1.0
CATEGORY:	Codec
VERSION:	1.0
SUMMARY:	<p>This module processes all responses from the codec and routes the feedback to the proper control module. This module connects to a Cisco codec.</p>
GENERAL NOTES:	<p>The Cisco Touch 10 Room Control module suite allows the Cisco Touch 10 touch screen used with Cisco codecs to control other devices through the Crestron processor. The Cisco Touch 10 is programmed by going to the web page of the Cisco codec and selecting Integration-> In-Room Control Editor. The controls added will be assigned a widget Id either automatically or be the person editing the controls. Those widget Ids will be needed for the Crestron modules to work. This module was tested with a Cisco SX80. It will also work with the following Cisco codecs:</p> <ul style="list-style-type: none">• MX200 G2• MX300 G2• MX700• MX800• SX10• SX20 <p>The processor module will check to see how many control modules are connected when the program starts up. The check is done by checking for defined signals. The module will then send a message to each output at start up to determine which outputs have control modules connected. Therefore, you may skip toControlModules[*].</p> <p>NOTE: ALL CONTROL MODULES MUST BE LOCATED IN THE SAME PROGRAM AS THE CONTROL PROCESSOR MODULE. IF COMNTROLS ARE REQUIRED IN OTHER PROGRAM SLOTS OR PROCESSORS, THE CONTROL AND FEEDBACK SIGNALS SHOULD BE PASSED. DO NOT PASS THE toControlModules[*] or fromControlModules SIGNALS.</p> <p>The processor will need to ask each connected module for its widget id. This is done when the initialize input is pulsed on the processor module. The processor will also register with the codec for the proper event feedback. When each module is initialized, it will send its initial value to the codec. Those commands to the codec are sent to the processor module. The processor module will then forward the commands to the codec with no further delays. The control modules will not send any values until they have been initialized. The only exception to that rule is the Cisco Touch 10 Room Control Text Box module. That module does not get any feedback from the Cisco so it does not need to be initialized.</p> <p>NOTE: THERE SHOULD ONLY BE ONE WIDGET CONTROL MODULE PER toControlModules[*] OUTPUT. PUTTING MORE THAN WIDGET CONTROL MODULE ON AN OUTPUT WILL RESULT IN THE CONTROL MODULES CONNECTED TO THE OUTPUT SHOWING AN ERROR.</p> <p>This module is for 3-series and later processors only.</p>
CRESTRON HARDWARE REQUIRED:	C2I-*-COM, C2I-*ENET-*

Partner: Cisco
 Model: SX80
 Device Type: Codec




SETUP OF CRESTRON HARDWARE:	RS232 Baud: 115200 Parity: None Data Bits: 8 Stop Bits: 1 SSH								
VENDOR FIRMWARE:	8.1.x								
VENDOR SETUP:	The Cisco Touch 10 will need to be programmed to have room control widgets on it. That is done by going to the web page of the Cisco codec and selecting Integration - > In-Room Control Editor. Contact Cisco for more information on how to use the In-Room Control Editor. The Crestron demo program includes a room control file that was used for testing. You may load that file to the Cisco Touch 10 using the In-Room Control Editor.								
CABLE DIAGRAM:	RS232: MC3: CNSP-121 All Other 3-Series: <table border="0"> <tr> <td>Crestron</td> <td>Cisco</td> </tr> <tr> <td>Pin: TX</td> <td>Pin: 3</td> </tr> <tr> <td>Pin: RX</td> <td>Pin: 2</td> </tr> <tr> <td>Pin: GND</td> <td>Pin: 5</td> </tr> </table>	Crestron	Cisco	Pin: TX	Pin: 3	Pin: RX	Pin: 2	Pin: GND	Pin: 5
Crestron	Cisco								
Pin: TX	Pin: 3								
Pin: RX	Pin: 2								
Pin: GND	Pin: 5								



Partner: Cisco
 Model: SX80
 Device Type: Codec



3-Series Straight Through



CONTROL:

initialize	D	Pulse to initialize the Cisco Touch 10 Room Control modules.
fromDevice	S	Serial signal to be routed from the rx\$ of a 2-way serial com port.
fromControlModules	S	Serial signal to be routed from the toProcessorModule output of all Cisco Touch 10 Room Control modules. NOTE: THERE SHOULD ONLY BE ONE WIDGET CONTROL MODULE PER toControlModules[*] OUTPUT. PUTTING MORE THAN WIDGET CONTROL MODULE ON AN OUTPUT WILL RESULT IN THE CONTROL MODULES CONNECTED TO THE OUTPUT SHOWING AN ERROR.

FEEDBACK:

initializeComplete	D	High to indicate that the initialization process is complete.
toDevice	S	Serial signal to be routed to the tx\$ of a 2-way serial com port.
toControlModules	S	Serial signals to be routed to the fromProcessorModule input on the control modules. This can be expanded to 100 outputs. Only expand these outputs to the number needed.

Partner: Cisco
Model: SX80
Device Type: Codec

**TESTING:**

OPS USED FOR TESTING:	CP3: 1.501.0013
SIMPL WINDOWS USED FOR TESTING:	4.03.20
DEVICE DB USED FOR TESTING:	75.05.001.00
CRES DB USED FOR TESTING:	56.05.001.00
SYMBOL LIBRARY USED FOR TESTING:	994
SAMPLE PROGRAM:	Cisco Touch 10 Room Controls v1.0 Demo
REVISION HISTORY:	v1.0 – Initial Release