

Manufacturer: Bose
Model: EX Series
Device Type: Digital Signal Processor



GENERAL INFORMATION

SIMPLWINDOWS NAME:	Bose EX Series Router Control v3.1
CATEGORY:	Conferencing
VERSION:	3.1
SUMMARY:	The Routing Control component controls the routing functionality of a Router module.
CRESTRON HARDWARE REQUIRED:	Crestron 3-Series or 4-Series processor.
VENDOR FIRMWARE:	v2.520

Manufacturer: Bose
Model: EX Series
Device Type: Digital Signal Processor

**PARAMETERS:**

Module_Name	Set to the name of the module to be controlled.
Output_Channel	Set to the output channel of the module that the inputs will be routed to. This component can be instantiated as many times as needed to cover as many outputs needed.
Command_Processor_ID	The unique identifier for the command processor module this module will register with.

Manufacturer: Bose
Model: EX Series
Device Type: Digital Signal Processor

**CONTROL:**

New_Input	A	Set to the input number the module will manage the routing for.
Route_Input	D	Pulse to route the input value of the New_Input signal to the output specified in the Output_Channel parameter.
Deroute_Input	D	Pulse to deroute the input value of the New_Input signal to the output specified in the Output_Channel parameter.
Toggle_Input	D	Pulse to toggle the route of the input value of the New_Input signal to the output specified in the Output_Channel parameter.
Enable	D	Latch high to enable this component.

Manufacturer: Bose
Model: EX Series
Device Type: Digital Signal Processor

**FEEDBACK:**

Is_Initialized	D	Indicates the module is registered to the command processor and is synchronized with current device state when the signal is high, or not synchronized with current device state when the signal is low.
Input_Routed_Fb	A	Shows the current input routed to the output specified by the Output_Channel parameter.
Is_Routed	D	High to indicate the input specified by the New_Input signal is currently routed to the output specified by the Output_Channel parameter.
Is_Quarantined	D	Indicates that there was a problem getting this component initialized due to a configuration issue when the signal is high, or that no initialization issue occurred when the signal is low. A quarantined component will not prevent the command processor or other components from getting initialized.

Manufacturer: Bose
Model: EX Series
Device Type: Digital Signal Processor

**TESTING:**

OPS USED FOR TESTING:	CP3 1.8001.4666.20418 MC4 2.8000.00017
SIMPL WINDOWS USED FOR TESTING:	4.2000.00
CRES DB USED FOR TESTING:	214.0000.001.00
DEVICE DATABASE:	200.23000.001.00
SYMBOL LIBRARY USED FOR TESTING:	1176
SAMPLE PROGRAM:	Bose EX Series v3.1 IP Demo.smw Bose EX Series v3.1 RS232 Demo.smw
REVISION HISTORY:	v3.0 – Initial Release v3.1 – No updates have been performed