



Manufacturer: Gude Systems GmbH
Model: Expert PowerControl 8316
Device Type: Power Controller

CONTACT SUPPORT:

Table with 2 columns: Field Name and Value. Fields include COMPANY NAME, SUPPORT CONTACT, EMAIL ADDRESS, and NOTES.

GENERAL INFORMATION

Table with 2 columns: Field Name and Value. Fields include SIMPLWINDOWS NAME, CATEGORY, VERSION, SUMMARY, GENERAL NOTES, CRESTRON HARDWARE REQUIRED, SETUP OF CRESTRON HARDWARE, VENDOR FIRMWARE, VENDOR SETUP, and CABLE DIAGRAM.

©2013 Crestron Electronics, Inc.
15 Volvo Drive · Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

http://application.market.com

For more information please contact our Crestron Application Market team at applicationmarket@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CSP Members, A+ Partners and Certified Integrated Partners only. Specifications subject to change without notice.



Manufacturer: Gude Systems GmbH
 Model: Expert PowerControl 8316
 Device Type: Power Controller

CONTROL:

<i>Signal/Function Name</i>		
Enable_HTTPS	D	Set the input to "1" to enable HTTPS.
Px_on	D	Press to switch the port x on.
Px_off	D	Press to switch the port x off.
Px_reset	D	Press to reset the port x.

FEEDBACK:

Px_on_fb	D	Indicates the port x is on.
Px_off_fb	D	Indicates the port x is off.
Px_name	S	Indicates the current port name.
Px_voltage	S	Indicates the voltage at the port x in V.
Px_current	S	Indicates the current consumption of port x in A.
Px_power	S	Indicates the power consumption of port x in W.
Px_icurrent	A	Indicates the current consumption of port x in mA.
Sx_temperature	S	Indicates the temperature measured by the external sensor x.
Sx_humidity	S	Indicates the humidity measured by the external sensor x.
Sx_pressure	S	Indicates the pressure measured by the external sensor x.
Line_Voltage	S	Indicates the voltage at the line-port in V.
Line_Current	S	Indicates the current at the line-port in A.
Line_Frequency	S	Indicates the frequency at the line-port in Hz.

©2013 Crestron Electronics, Inc.
 15 Volvo Drive · Rockleigh, NJ 07647
 800.237.2041 / 201.767.3400

<http://application.market.com>

For more information please contact our Crestron Application Market team at applicationmarket@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CSP Members, A+ Partners and Certified Integrated Partners only. Specifications subject to change without notice.



Manufacturer: Gude Systems GmbH
 Model: Expert PowerControl 8316
 Device Type: Power Controller

Line_PhaseIU	S	Indicates the phase IU at the line-port in degree.
Line_ActivePower	S	Indicates the active power at the line-port in W.

PARAMETERS:

ipadress	S	IP address of the device being controlled.
username	S	The username for the password protection (if enabled).
password	S	The password for the password protection (if enabled).

TESTING:

OPS USED FOR TESTING:	CP3N 1.601.3935.27221
SIMPL WINDOWS USED FOR TESTING:	V 4.3.0
DEVICE DB USED FOR TESTING:	V 200.440
CRES DB USED FOR TESTING:	V 228.40
SAMPLE PROGRAM:	Gude Demo 8316 v7.0.smw
REVISION HISTORY:	V 7.0 Added Line Current, Frequency, PhaseUI, Power.



Manufacturer: Gude Systems GmbH
Model: Expert PowerControl 8316
Device Type: Power Controller

©2013 Crestron Electronics, Inc.
15 Volvo Drive · Rockleigh, NJ 07647
800.237.2041 / 201.767.3400

<http://application.market.com>

For more information please contact our Crestron Application Market team at applicationmarket@crestron.com. The information contained on this document is privileged and confidential and for use by Crestron Authorized Dealers, CSP Members, A+ Partners and Certified Integrated Partners only. Specifications subject to change without notice.