


Partner: Integra  
 Model: DBS-30.2  
 Device Type: Blu-ray Player



**GENERAL INFORMATION**

<b>SIMPLWINDOWS NAME</b>	Integra DBS-30.2 Serial v1.0
<b>CATEGORY</b>	DVD/Blu-ray
<b>VERSION</b>	1.0
<b>SUMMARY</b>	This module provides control and true feedback for the Integra DBS-30.2 DVD/Blu-ray player.
<b>GENERAL NOTES</b>	This module will control the DBS-30.2 DVD/Blu-ray player. It should also control the DBS-50.2 and the DBS-30.1 DVD/Blu-ray players.  <b>NOTE: THIS MODULE IS 2-SERIES ONLY.</b>
<b>CRESTRON HARDWARE REQUIRED</b>	C2COM-2/3, C2COMI, ST-COM
<b>SETUP OF CRESTRON HARDWARE</b>	RS232 Baud: 9600 Parity: None Data Bits: 8 Stop Bits: 1
<b>VENDOR FIRMWARE</b>	N/A
<b>VENDOR SETUP</b>	N/A
<b>CABLE DIAGRAM</b>	CNSP-121



**Partner: Integra**  
**Model: DBS-30.2**  
**Device Type: Blu-ray Player**

**CONTROL**

<b>Power_On</b>	D	Pulse to turn the power on.
<b>Power_Off</b>	D	Pulse to turn the power off.
<b>Power_Toggle</b>	D	Pulse to toggle the power on/off.
<b>Play</b>	D	Pulse to play the disc.
<b>Pause</b>	D	Pulse to pause the disc.
<b>Stop</b>	D	Pulse to stop the disc.
<b>Next_Track</b>	D	Pulse to skip to the next track.
<b>Previous_Track</b>	D	Pulse to skip to the previous track.
<b>Scan_Forward</b>	D	Pulse to scan forward.
<b>Scan_Reverse</b>	D	Pulse to scan backwards.
<b>Up_Arrow</b>	D	Pulse to move the selection up
<b>Down_Arrow</b>	D	Pulse to move the selection down.
<b>Left_Arrow</b>	D	Pulse to move the selection left.
<b>Right_Arrow</b>	D	Pulse to move the selection right.
<b>Enter</b>	D	Pulse to send enter command.
<b>Return</b>	D	Pulse to send return command.
<b>Home</b>	D	Pulse to send home command.
<b>Menu</b>	D	Pulse to show the menu.

**Partner: Integra**  
**Model: DBS-30.2**  
**Device Type: Blu-ray Player**



<b>Title</b>	D	Pulse to show the title screen.
<b>Display</b>	D	Pulse to display stream info.
<b>Angle</b>	D	Pulse to change the angle.
<b>Audio</b>	D	Pulse to change the audio.
<b>Subtitle</b>	D	Pulse to change the subtitle.
<b>Key_*</b>	D	Pulse to send corresponding digit.
<b>Search</b>	D	Pulse to begin a search.
<b>Repeat</b>	D	Pulse to repeat.
<b>A-B_Repeat</b>	D	Pulse to set an A-B repeat.
<b>From_Device</b>	S	Serial signal to be routed from a 2-way serial com port.

## FEEDBACK

<b>Power_Is_*</b>	D	High to indicate current power state.
<b>Player_Is_*</b>	D	High to indicate current player state.
<b>Current_Disc_Type_Text</b>	S	Serial signal to indicate the type of disc currently inserted.
<b>Current_Title_Text</b>	S	Serial signal to indicate the current disc title.
<b>Current_Chapter_Text</b>	S	Serial signal to indicate the current chapter text.
<b>Current_Elapsed_Time_Text</b>	S	Serial signal to indicate the current elapsed playback time.
<b>To_Device</b>	S	Serial signal to be routed to a 2-way serial com port.

**Partner: Integra**  
**Model: DBS-30.2**  
**Device Type: Blu-ray Player**

**TESTING**

<b>OPS USED FOR TESTING</b>	v4.001.1012
<b>SIMPL WINDOWS USED FOR TESTING</b>	V3.01.24
<b>CRESTRON DATABASE USED FOR TESTING</b>	v24.00.039.00
<b>DEVICE DATABASE USED FOR TESTING</b>	v32.00.019.00
<b>SAMPLE PROGRAM</b>	Integra DBS-30.2 Serial v1.0 Demo PRO2.smw
<b>REVISION HISTORY</b>	V1.0 – Initial release.