

**Partner: Sony**  
**Model: SNC-RZ50P**  
**Device Type: IP Camera**



## GENERAL INFORMATION

<b>SIMPLWINDOWS NAME:</b>	Sony SNC-RZ50P IP Camera v1.0.umc
<b>CATEGORY:</b>	Camera
<b>VERSION:</b>	1.0
<b>SUMMARY:</b>	This module will control the pan/tilt/zoom functions as well as presets of this Sony IP camera.
<b>GENERAL NOTES:</b>	This module is for IP control only, the actual IP address of the camera must be known and entered into the parameter field of the module.
<b>CRESTRON HARDWARE REQUIRED:</b>	C2-ENET-1, C2-ENET-2
<b>SETUP OF CRESTRON HARDWARE:</b>	NONE
<b>VENDOR FIRMWARE:</b>	
<b>VENDOR SETUP:</b>	none
<b>CABLE DIAGRAM:</b>	N/A

## CONTROL:

<b>Pan_Left</b>	D	Press and hold to pan the camera left, release to stop
<b>Pan_Right</b>	D	Press and hold to pan the camera right, release to stop
<b>Tilt_Up</b>	D	Press and hold to tilt the camera up, release to stop
<b>Tilt_Down</b>	D	Press and hold to tilt the camera down, release to stop
<b>Zoom_In</b>	D	Press and hold to zoom the camera in, release to stop
<b>Zoom_Out</b>	D	Press and hold to zoom the camera out, release to stop
<b>Preset_1</b>	D	Pulse to recall preset 1, press and hold to save the preset to its current location

**Partner: Sony**  
**Model: SNC-RZ50P**  
**Device Type: IP Camera**



Preset_2	D	Pulse to recall preset 2, press and hold to save the preset to its current location
Preset_3	D	Pulse to recall preset 3, press and hold to save the preset to its current location
Preset_4	D	Pulse to recall preset 4, press and hold to save the preset to its current location
Preset_5	D	Pulse to recall preset 5, press and hold to save the preset to its current location
Preset_6	D	Pulse to recall preset 6, press and hold to save the preset to its current location
Preset_7	D	Pulse to recall preset 7, press and hold to save the preset to its current location
Preset_8	D	Pulse to recall preset 8, press and hold to save the preset to its current location
Preset_9	D	Pulse to recall preset 9, press and hold to save the preset to its current location
Preset_10	D	Pulse to recall preset 10, press and hold to save the preset to its current location
Preset_11	D	Pulse to recall preset 11, press and hold to save the preset to its current location
Preset_12	D	Pulse to recall preset 12, press and hold to save the preset to its current location
Preset_13	D	Pulse to recall preset 13, press and hold to save the preset to its current location
Preset_14	D	Pulse to recall preset 14, press and hold to save the preset to its current location
Preset_15	D	Pulse to recall preset 15, press and hold to save the preset to its current location
Preset_16	D	Pulse to recall preset 16, press and hold to save the preset to its current location
Home	D	Pulse to send the camera to it's home position

## PARAMETERS:

IP Address	P	Specifies the IP address of the camera to be controlled
Pan Tilt Speed	P	Specifies the Pan/Tilt speed in decimal, valid range 1d-24d
Zoom Speed	P	Specifies the Pan/Tilt speed in decimal, valid range 1d-8d
Preset Hold Time	P	Specifies the time needed for an individual preset button to be held in order to save the preset

**Partner: Sony**  
**Model: SNC-RZ50P**  
**Device Type: IP Camera**

**TESTING:**

<b>OPS USED FOR TESTING:</b>	3-series 1.002.0000, 2-series 4.003.0015
<b>SIMPL WINDOWS USED FOR TESTING:</b>	3.10.20
<b>CRES DB USED FOR TESTING:</b>	29.01.004.00
<b>DEVICE DATABASE:</b>	39.00.005.00
<b>SYMBOL LIBRARY USED FOR TESTING:</b>	772
<b>SAMPLE PROGRAM:</b>	Sony SNC-RZ50P IP Camera v1.0 Demo MC3.smw
<b>REVISION HISTORY:</b>	V. 1.0