

**Partner: Sony**  
**Model: VPL-VW1000ES**  
**Device Type: LCD Projector**



## GENERAL INFORMATION

<b>SIMPLWINDOWS NAME:</b>	Sony VPL-VW1000ES IP v1.0
<b>CATEGORY:</b>	TV/Video Projector
<b>VERSION:</b>	1.0
<b>SUMMARY:</b>	This module provides TCP/IP control and feedback for the Sony VPL-VW1000ES.
<b>GENERAL NOTES:</b>	<p>This module will control the Sony VPL-VW1000ES projector. True feedback is provided for all functions including elapsed lamp hours. When any command is sent to the projector, it will acknowledge that the command was processed properly and the corresponding feedback will be reflected at the outputs of this module. Picture settings will only be updated when the appropriate input is selected.</p> <p>This module was tested with the Sony VPL-VW1000ES.</p> <p>This module is System Builder compatible.</p>
<b>CRESTRON HARDWARE REQUIRED:</b>	C21-COM6, C2-COM2/3, CNXCOM-6, CNX-COM2, ST-COM, C21-MC3-COM2
<b>SETUP OF CRESTRON HARDWARE:</b>	TCP/IP Client: Port: 53484
<b>VENDOR FIRMWARE:</b>	N/A
<b>VENDOR SETUP:</b>	You must go to the projector's web page. Go to Setup and login. Then go to Advanced Menu\PJ Talk. Check Start PJ Talk Service. Enter the IP address of the Crestron processor that will be controlling the projector in the Host Address. Be sure to click Apply before exiting.
<b>CABLE DIAGRAM:</b>	N/A

## CONTROL:

<b>Power_&lt;On/Off/Toggle&gt;</b>	D	Pulse to turn the projector on or off.
<b>Input_*</b>	D	Pulse to select the desired input.
<b>Aspect_*</b>	D	Pulse to set the aspect ratio.
<b>Picture_Position_*</b>	D	Pulse to recall the picture position preset. Picture position presets are used to store lens positions.
<b>Picture_Mode_*</b>	D	Pulse to set the picture mode.
<b>Lamp_Control_&lt;High/Low/Toggle&gt;</b>	D	Pulse to set the lamp brightness.

**Partner: Sony**  
**Model: VPL-VW1000ES**  
**Device Type: LCD Projector**



Picture_Mute_<On/Off/Toggle>	D	Pulse to turn picture mute on or off.
Menu	D	Pulse to enter or exit on screen menu.
Up	D	Pulse to navigate on screen menu.
Down	D	Pulse to navigate on screen menu.
Left	D	Pulse to navigate on screen menu.
Right	D	Pulse to navigate on screen menu.
Enter	D	Pulse to select highlighted item in menu.
Contrast_<Up/Down>	D	Press to adjust contrast.
Brightness_<Up/Down>	D	Press to adjust brightness.
Color_<Up/Down>	D	Press to adjust color.
Hue_<Up/Down>	D	Press to adjust hue.
Sharpness_<Up/Down>	D	Press to adjust sharpness.
Focus_<In/Out>	D	Press to adjust focus.
Zoom_<In/Out>	D	Press to adjust zoom.
Lens_Shift_*	D	Press to adjust lens shift.
Advanced_Iris_*	D	Pulse to set advance iris setting.
Film_Mode_*	D	Pulse to set film mode.
Motion_Enhancer_*	D	Pulse to select motion enhancer setting.
Set_2D-3D_Display_*	D	Pulse to select 2D or 3D display output.
Set_3D_Format_*	D	Pulse to select the type of 3D format.
Set_3D_Depth_*	D	Pulse to select the 3D depth.
Simulated_3D_Effect_*	D	Pulse to select the type of simulated 3D effect.
Set_3D_Brightness_*	D	Pulse to set brightness of 3D.
Poll_Enable	D	Latch high to enable polling.

**Partner: Sony**  
**Model: VPL-VW1000ES**  
**Device Type: LCD Projector**



Poll_Settings	D	Latch high to enable polling of settings.
Connect	D	Latch high cause the TCP/IP Client to connect to the projector.
{{TCP/IP_Client_>>_Connect-F}}	D	Digital signal to be routed from the Connect-F output on the TCP/IP Client.
{{TCP/IP_Client_>>_status}}	A	Analog signal to be routed from the status output of the TCP/IP Client.
{{TCP/IP_Client_>>_RX\$}}	S	Serial signal to be routed from the RX\$ output of the TCP/IP Client.

### PARAMETER:

Port Number	P	Port number for TCP/IP connection. For use in System Builder only.
-------------	---	--

### FEEDBACK:

Power_Is_<On/Off>	D	High to indicate the current power state.
Is_Warming_Up	D	High to indicate that the projector is warming up.
Is_Cooling_Down	D	High to indicate that the projector is cooling down.
Input_Is_*	D	High to indicate the current input.
Aspect_Is_*	D	High to indicate the current aspect.
Picture_Position_Is_*	D	High to indicate the currently selected picture position preset. Picture position presets are used to store lens positions.
Picture_Mode_Is_*	D	High to indicate the current picture mode selected.
Lamp_Control_Is_<High/Low>	D	High to indicate the lamp brightness setting.
Picture_Mute_Is_<On/Off>	D	High to indicate if picture mute is on or off.
Contrast_Gauge	A	Analog value indicating current contrast value.
Brightness_Gauge	A	Analog value indicating current brightness value.
Color_Gauge	A	Analog value indicating current color value.
Hue_Gauge	A	Analog value indicating current hue value.
Sharpness_Gauge	A	Analog value indicating current sharpness value.

**Partner: Sony**  
**Model: VPL-VW1000ES**  
**Device Type: LCD Projector**



Advanced_Iris_Is_*	D	High to indicate current advanced iris setting.
Film_Mode_Is_*	D	High to indicate film mode setting.
Motion_Enhancer_Is_*	D	High to indicate current motion enhancer setting.
Set_2D-3D_Display_Is_*	D	High to indicate 2D or 3D display output.
Set_3D_Format_Is_*	D	High to indicate the type of 3D format.
Set_3D_Depth_Is_*	D	High to indicate the 3D depth.
Simulated_3D_Effect_Is_*	D	High to indicate the type of simulated 3D effect.
Set_3D_Brightness_Is_*	D	High to indicate the brightness of the 3D.
Lamp_Hours	A	Analog value indicating lamp hours.
Connect-F	D	High to indicate that the TCP/IP Client is connected.
Connection_Status_Text	S	Serial signal indicating the current TCP/IP Client connection status.
{{Connect_>>_TCP/IP_Client}}	D	Digital signal to be routed to the Connect input on the TCP/IP Client.
{{TX\$_>>_TCP/IP_Client}}	S	Serial signal to be routed to the TX\$ input on the TCP/IP Client.

## TESTING:

OPS USED FOR TESTING:	2-Series v4.003.0015 3-Series v1.002.0000
SIMPL WINDOWS USED FOR TESTING:	3.10.20
CRES DB USED FOR TESTING:	29.02.103.00
DEVICE DB USED FOR TESTING	39.00.005.00
SYMBOL LIBRARY USED FOR TESTING:	772
SAMPLE PROGRAM:	Sony VPL-VW1000ES IP v1.0 Demo
REVISION HISTORY:	V. 1.0 – Original release.